Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power	Power	Right	Right
Info	Info / Angle	Vol +	Vol +
Lang	Audio / Lang I/II	List	Smart / List
Mute	Mute / Dimmer	CH-	CH- / Page-
[...]	Subtitle / EQ	Down	Down
♥	Fav / Marker / PC	←	Back / Return
▲	Shift + Up	1	1
[≡]	Text / Goto	2	2
EPG	Guide / EPG / -/--	3	3
▼	Shift + Down	[<>]	Picture / Format
Menu	Menu / Home	4	4
CH+	CH+ / Page+	5	5
Up	Up	6	6
Exit	Exit / Cancel / Clear	TV/R	TV/Radio /
Left	Left	7	7
Vol -	Vol -	8	8
OK	OK	9	9

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
0	0	HDMI - SAT 0	0		
PREV	I <<	PRESET-	I << / Preset-		
FRW	<<	TUNE-	<< / Tune-		
FFW	>>	TUNE+	>> / Tune+		
NEXT	>>I	PRESET+	>>I / Preset+		
PLAY	Play	SLOW	Play / Slow		
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze		
STOP	Stop	HOLD	Stop / Hold		
REC	Rec	REC MODE	Rec / Rec Mode		
TIMER	Red/ Timer	TIMER SLEEP	Sleep / Timer		
TIMER	Red/ Timer	NETFLIX SEARCH	Red / Netflix / Search		
EJECT	Eject	SURROUND	Eject / Surround		
EJECT	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		