| Originalfernbedienung | Ersatzfernbedienung |
|---|---|
| Power Receiver | Power |
| 1 | 1 |
| VCR / DVR | Shift + 4 |
| 2 | 2 |
| CBL / SAT | Shift + 0 |
| 3 | 3 |
| 4 | 4 |
| AUX | Shift + 7 |
| 5 | 5 |
| Multi CH | Shift + 1 |
| 6 | 6 |
| DVD | Shift + 2 |
| 7 | 7 |
| TAPE | Shift + 5 |
| 8 | 8 |
| TUNER | Shift + 6 |
| 9 | 9 |

| Originalfernbedienung | Ersatzfernbedienung |
|---|---|
| CD | Shift + 3 |
| D. TUN | Smart / List |
| Dimmer | Shift + Mute / Dimmer |
| 0 | 0 |
| Sleep | Sleep / Timer |
| CH+ | CH+ / Page+ |
| Vol + | Vol + |
| CH- | CH- / Page- |
| Vol - | Vol - |
| SP A/B | Info / Angle |
| Up | Up |
| Muting | Mute / Dimmer |
| Left | Left |
| Enter | OK |
| Right | Right |
| Setup | Setup / OPT / |
| Down | Down |

| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Return | Back / Return | L. Night | Menu / Home |
| Pause / Play Rev | Pause / Step / Freeze | Cine FLTR | D. Menu / Top |
| Play | Play / Slow | | |
| Stop | Stop / Hold | | |
| << | << / Tune- | | |
| >> | >> / Tune+ | | |
| I << | I << / Preset- | | |
| >>I | >>I / Preset+ | | |
| Stereo | Audio / Lang I/II | | |
| Surround | Eject / Surround | | |
| < Listening Mode | Shift + I << / Preset- | | |
| Listening Mode > | Shift + >>I / Preset+ | | |
| Test Tone | Red / Netflix / Search | | |
| CH Sel | Green / APP / Repeat | | |
| Level - | Yellow / YouTube / Repeat | | |
| Level + | Blue / Prime Video / Random | | |
| Display | Display / Media | | |

| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Power | Power | Left / Playlist / Ca | Left |
| 1 | 1 | Enter | OK |
| 2 | 2 | Right / Playlist / C | Right |
| 3 | 3 | Setup | Setup / OPT / |
| 4 | 4 | Down | Down |
| 5 | 5 | Return | Back / Return |
| 6 | 6 | Pause | Pause / Step / Freeze |
| 7 | 7 | Play | Play / Slow |
| 8 | 8 | Stop | Stop / Hold |
| 9 | 9 | << | << / Tune- |
| +10/ 10/ - / - - | Guide / EPG / - / - - | >> | >> / Tune+ |
| 0/ 11 | 0 | I << | I << / Preset- |
| CLR/ 12/ Sleep | Sleep / Timer | >>I | >>I / Preset+ |
| CLR/ 12/ Sleep | Exit / Cancel / Clear | Stereo | Sound / Title |
| Guide/ Top | D. Menu / Top | Surround | Eject / Surround |
| Up | Up | < Listening Mode | SHIFT + PRESET- Shift + I << / Preset- |
| Previous Menu/ Muting | Menu / Home | Listening Mode > | SHIFT + PRESET+ Shift + >>I / Preset+ |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|---|---|
| AUDIO / TEST TONE | Audio | LANG I/II / AUDIO | Audio / Lang I/II | | |
| SUBTITLE / CH SEL | Subtitle | EQ / SUBTITLE | Subtitle / EQ | | |
| RANDOM / LEVEL- | Level-/Random | Prime Video / RANDOM | Blue / Prime Video / Random | | |
| REPEAT / LEVEL+ | Level+/Repeat | APP / REPEAT | Green / APP / Repeat | | |
| DISPLAY | Display | MEDIA / DISPLAY | Display / Media | | |
| PLAY MODE / VCR | Play Mode VCR | SHIFT + VIDEO 4 | Shift + 4 | | |
| L NIGHT / DVD | Play Mode DVD | SHIFT + DVD 2 | Shift + 2 | | |
| CINE FLTR / HDD | Play Mode HDD | SHIFT + AUX-HDD 7 | Shift + 7 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|---|---|---|---|
| STANDBY/ON | Power | | Power | VOL | Vol - | VOL | Vol - |
| VCR/DVR | 1 | TV 1 | 1 | | Pause | STEP-FREEZE | Pause / Step / Freeze |
| CBL/SAT | 2 | DVD 2 | 2 | | Play | SLOW | Play / Slow |
| | 3 | CD-STB 3 | 3 | | Stop | HOLD | Stop / Hold |
| AUX | 4 | VIDEO 4 | 4 | | << | TUNE- | << / Tune- |
| MULTI CH | 5 | TAPE 5 | 5 | | >> | TUNE+ | >> / Tune+ |
| DVD | 6 | TUNER 6 | 6 | | I << | PRESET- | I << / Preset- |
| TAPE | 7 | AUX-HDD 7 | 7 | | >>I | PRESET+ | >>I / Preset+ |
| TUNER | 8 | USB 8 | 8 | STEREO | Stereo | LANG I/II AUDIO | Audio / Lang I/II |
| CD | 9 | BLUETOOTH 9 | 9 | SURROUND | Surround | SURROUND | Eject / Surround |
| | +10/ 10/ -/ -- | -/-- GUIDE EPG | Guide / EPG / -/-- | | < Listening Mode | SHIFT + PRESET- | Shift + I << / Preset- |
| DIMMER | 0 | HDMI-SAT 0 | 0 | | Listening Mode > | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| CLR SLEEP | CLR/ 12/ Sleep | TIMER SLEEP | Sleep / Timer | RANDOM LEVEL- | Level - / Random | Prime Video RANDOM | Blue / Prime Video / Random |
| CLR SLEEP | CLR/ 12/ Sleep | CLEAR EXIT CANCEL | Exit / Cancel / Clear | REPEAT LEVEL+ | Level +/ Repeat | APP REPEAT | Green / APP / Repeat |
| CH DISC ALBUM | Disc/ Album | CH PAGE | CH+ / Page+ | DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| VOL | Vol + | VOL | Vol + | | | | |
| CH DISC ALBUM | Disc/ Album CH- | CH PAGE | CH- / Page- | | | | |

| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Standby / On | Power | Up | Up |
| VCR/DVR | 4 | Muting | Mute / Dimmer |
| CBL/SAT | 0 | Left/Playlist/Ca | Left |
| AUX | 7 | Enter | OK |
| Multi CH | 1 | Right/Playlist/C | Right |
| DVD | 2 | Setup | Setup / OPT / |
| Tape | 5 | Down | Down |
| Tuner | 6 | Return | Back / Return |
| CD | 3 | Rev. Play | Pause / Step / Freeze |
| D. Tun | Smart / List | Play | Play / Slow |
| Dimmer | Shift + Mute / Dimmer | Stop | Stop / Hold |
| CLR / Sleep | Sleep / Timer | << | << / Tune- |
| CLR / Sleep | Exit / Cancel / Clear | >> | >> / Tune+ |
| CH Disc | CH+ / Page+ | Stereo | Audio / Lang I/II |
| Vol + | Vol + | Surround | Eject / Surround |
| CH Disc Album | CH- / Page- | < Listening Mode | I << / Preset- |
| Vol - | Vol - | Listening Mode > | >>I / Preset+ |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|---|---|
| AUDIO TEST TONE | Test Tone | NETFLIX SEARCH | Red / Netflix / Search | | |
| SUBTITLE CH SEL | CH Sel | APP REPEAT | Green / APP / Repeat | | |
| RANDOM LEVEL- | Level - | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| REPEAT LEVEL+ | Level + | Prime Video RANDOM | Blue / Prime Video / Random | | |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media | | |
| L NIGHT DVD | L. Night / Play Mode DVD | HOME MENU | Menu / Home | | |
| CINE FLTR HDD | Cine FLTR / Play Mode HDD | TOP MENU D.MENU | D. Menu / Top | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |