Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
DVD	DVD	SHIFT + DVD 2	Shift + 2
OPEN/CLOSE EJECT	Open / Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
RETURN	Return	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DISC MENU	Disc Menu	TOP MENU D.MENU	D. Menu / Top
▲	Up	▲	Up

Originalfernbedienung		Ersatzfernbedienung	
SYSTEM MENU	System Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
⏮	I <<	PRESET- ⏮	I << / Preset-
▼	Down	▼	Down
⏭	>>I	PRESET+ ⏭	>>I / Preset+
STOP ■	Stop	HOLD ■	Stop / Hold
PLAY ▶	Play	SLOW ▶	Play / Slow
PAUSE/STEP ⏸	Pause / Step	STEP - FREEZE ⏸	Pause / Step / Freeze
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ANGLE	Angle	ANGLE INFO	Info / Angle
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
TITLE LP	Title	TITLE SOUND	Sound / Title		
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random		

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power	Power	Left	Left
TV / VCR	TV/ Radio /	OK	OK
VCR	Shift + 4	Right	Right
Eject	Eject / Surround	I <<	I << / Preset-
1	1	Down	Down
2	2	>>I	>>I / Preset+
3	3	Stop	Stop / Hold
4	4	Play	Play / Slow
5	5	Pause / Step	Pause / Step / Freeze
6	6	Marker	Fav / Marker / PC
7	7	Search	Red / Netflix / Search
8	8	Input	AV / Input / RDS
9	9	Rec / ITR	Rec / Rec Mode
0	0	Program	Shift + TV/ Radio / Program
Display	Display / Media	Clear	Exit / Cancel / Clear
Up	Up	LP	Setup / OPT /
System Menu	Menu / Home	C. Lock	Back / Return

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
SHOW VIEW / VIDEO PLUS Show View / Video Plus	LIST / SMART Smart / List		