Originalfernbedienung		Ersatzfernbedienung	
STANDBY/ON	Standby/On		Power
CD DVD	DVD/CD	A	Red
FM/AM TUNER	Tuner/FM/AM	B	Green
TV	TV	C	Yellow
L1/L2 LINE	Line/L1/L2	D	Blue
DISPLAY	Display	DISPLAY INFO	Info
OPEN/CLOSE	Open/Close	ZOOM	Eject
	I<<		I<<
	>>I		>>I
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	II>/I>/>>		>>
	<</I</I		<<
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back
MUTE	Mute	MUTE	Mute

Originalfernbedienung		Ersatzfernbedienung	
SOUND	Sound	SOUND DUAL	Dual
ENTER	Enter	OK	Ok
TUNE +	Up/Tune+		Up
TUNE -	Down/Tune-		Down
ST+	Right/ST+		Right
ST-	Left/ST-		Left
MASTER VOLUME -	Volume Master-	VOL -	Vol -
MASTER VOLUME +	Volume	VOL +	Vol +
BASS MODE AUTO	Auto	REPEAT TEXT	Text
BASS MODE AUTO	Bass Mode	SETTINGS OPT	Options
DIALOGUE SURROUND	Dialogue	APP MEDIA	Media
DIALOGUE SURROUND	Surround	DISC NAV LIST	List
VIRTUAL SB ADVANCED	Virtual SB	PICTURE FORMAT	Format
VIRTUAL SB ADVANCED	Advanced	ECO 3D	3D
PROGRAM AUDIO	Program	PROG SLEEP	Sleep
PROGRAM AUDIO	Audio	SHIFT + SOUND DUAL	Shift + Dual
REPEAT SUBTITLE	Repeat	SHIFT + REPEAT TEXT	Shift + Text

Originalfernbedienung		Ersatzfernbedienung	
REPEAT SUBTITLE	Subtitle	AD SUBT	Subt
RANDOM ANGLE	Random	SHIFT + SEARCH TV/R	Shift + TV/R
RANDOM ANGLE	Angle	SEARCH TV/R	TV/R
ZOOM 1	1	1	1
ZOOM 1	Zoom	SHIFT + ZOOM ⏏	Shift + Eject
TOP MENU 2	2	2	2
TOP MENU 2	Top Menu	TOP MENU MENU	Menu
HOME MENU 3	3	3	3
HOME MENU 3	Home Menu	SHIFT + 3	Shift + 3
SYSTEM SETUP 4	4	4	4
SYSTEM SETUP 4	System Setup	SHIFT + 4	Shift + 4
TEST TONE 5	5	5	5
TEST TONE 5	Test Tone	SHIFT + 5	Shift + 5
CH LEVEL 6	6	6	6
CH LEVEL 6	CH Level	SHIFT + 6	Shift + 6
DIMMER 7	7	7	7
DIMMER 7	Dimmer	SHIFT + 7	Shift + 7

Originalfernbedienung		Ersatzfernbedienung	
QUIET/ MIDNIGHT 8	8	8	8
QUIET/ MIDNIGHT 8	Quiet/Midnight	SHIFT + 8	Shift + 8
TIMER/ CLOCK 9	9	9	9
TIMER/ CLOCK 9	Timer/Clock	SHIFT + 9	Shift + 9
FOLDER - 0	0	0	0
FOLDER - 0	Folder-	CH -	Ch -
CLR	CLR	-/-- GUIDE	Guide
FOLDER+ ENTER	Folder+	CH +	Ch +
FOLDER+ ENTER	Enter	FAV PRE-CH	Pre Ch
WIRELESS ROOM SETUP	Room Setup	HOME SMART	Smart
WIRELESS ROOM SETUP	Wireless	SHIFT + SETTINGS OPT	Shift + Options

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
CH+ Tv Control	Ch +		
CH- Tv Control	Ch -		
Vol + Tv Control	Vol +		
Power Tv Control	Power		
Input Tv Control	AV		
Vol - Tv Control	Vol -		