Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver		Power
BD/DVD	BD/DVD	SHIFT + DVD 2	Shift + 2
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + BLUETOOTH 9	Shift + 9
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV/CD	SHIFT + CD - STB 3	Shift + 3
PHONO	Phono	SHIFT + VIDEO 4	Shift + 4
NET	NET	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
USB	USB	SHIFT + USB 8	Shift + 8
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH/Disc/Album	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
ALBUM	CH/Disc/Album	CH PAGE −	CH- / Page-
VOL	Vol -	VOL −	Vol -

Originalfernbedienung		Ersatzfernbedienung	
	Up		Up
PLAYLIST	Left Playlist		Left
ENTER	Enter	OK	OK
PLAYLIST	Right Playlis		Right
Q SETUP	Q/Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO HOME	Home/Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	>>I	PRESET+	>>I / Preset+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
SEARCH MOVIE/TV A	Movie/Tv/Search/	NETFLIX SEARCH	Red / Netflix / Search
REPEAT MUSIC B	Music/Repeat/B	APP REPEAT	Green / APP / Repeat

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
RANDOM GAME C Game/ Random/	YouTube REPEAT A-B Yellow / YouTube / Repeat		
MODE STEREO D Stereo/ Mode/ D	Prime Video RANDOM Blue / Prime Video / Random		
1 1	TV 1 1		
2 2	DVD 2 2		
3 3	CD - STB 3 3		
4 4	VIDEO 4 4		
5 5	TAPE 5 5		
6 6	TUNER 6 6		
7 7	AUX - HDD 7 7		
8 8	USB 8 8		
9 9	BLUETOOTH 9 9		
--/--- 10 +10 D.TUN DIMMER +10/ - - / - - - 10/ Dimmer / D. Tun	-/-- GUIDE EPG Guide / EPG / - / - -		
11 0 0/ 11	HDMI - SAT 0 0		
12 CLR SLEEP CLR/ Sleep/ 12	PC FAV MARKER Fav / Marker / PC		
12 CLR SLEEP CLR/ Sleep/ 12	TIMER SLEEP Sleep / Timer		
12 CLR SLEEP CLR/ Sleep/ 12	CLEAR EXIT CANCEL Exit / Cancel / Clear		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
	Play BD/DVD	SLOW	Play / Slow
	Pause BD/DVD	STEP-FREEZE	Pause / Step / Freeze
	Stop BD/DVD	HOLD	Stop / Hold
	<< BD/DVD	TUNE-	<< / Tune-
	>> BD/DVD	TUNE+	>> / Tune+
	I<< BD/DVD	PRESET-	I<< / Preset-
	>>I BD/DVD	PRESET+	>>I / Preset+
AUDIO HOME	Audio BD/DVD	LANG I/II AUDIO	Audio / Lang I/II
TOP MENU SP/GUIDE	Top Menu	TOP MENU D.MENU	D.Menu / Top
Q SETUP	Setup BD/DVD	OPT-TOOLS SETUP	Setup / OPT /
MENU PREV CH	Menu BD/DVD	HOME MENU	Menu / Home
	Up BD/DVD		Up
PLAYLIST	Left BD/DVD		Left
ENTER	Enter BD/DVD	OK	OK
PLAYLIST	Right BD/DVD		Right
12 CLR SLEEP	CLR/12 BD/DVD	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originalfernbedienung		Ersatzfernbedienung	
	Down BD/DVD		Down
RETURN	Return BD/DVD	RETURN BACK	Back / Return
VOL	Vol + Receiver	VOL +	Vol +
BD/DVD	BD/DVD	LIST SMART	Smart / List
VOL	Vol - Receiver	VOL −	Vol -
CBL/SAT	CBL/SAT	MEDIA DISPLAY	Display / Media
1	1 BD/DVD	TV 1	1
2	2 BD/DVD	DVD 2	2
3	3 BD/DVD	CD-STB 3	3
4	4 BD/DVD	VIDEO 4	4
5	5 BD/DVD	TAPE 5	5
6	6 BD/DVD	TUNER 6	6
7	7 BD/DVD	AUX-HDD 7	7
8	8 BD/DVD	USB 8	8
9	9 BD/DVD	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10/--/--10	-/-- GUIDE EPG	Guide / EPG / -/--
11 0	0/11 BD/DVD	HDMI-SAT 0	0

Originalfernbedienung	Ersatzfernbedienung
CLR/12 BD/DVD	Fav / Marker / PC
Search BD/DVD	Red / Netflix / Search
Repeat BD/DVD	Green / APP / Repeat
Stereo/Mode	Yellow / YouTube / Repeat
Random	Blue / Prime Video / Random
Power CBL/SAT	Shift + Power
Play CBL/SAT	Shift + Play /
Pause CBL/SAT	Shift + Pause / Step /
Stop CBL/SAT	Shift + Stop /
<< CBL/SAT	Shift + << /
>> CBL/SAT	Shift + >> /
Setup CBL/SAT	Shift + Setup / OPT / Tools
Menu/Prev CH CBL/SAT	Shift + Menu /
Up CBL/SAT	Shift + Up
Left CBL/SAT	Shift + Left
Enter CBL/SAT	Shift + OK
Right CBL/SAT	Shift + Right

Originalfernbedienung	Ersatzfernbedienung
Down CBL/SAT	Shift + Down
Return CBL/SAT	Shift + Back / Return
CH Disc/Album+ CBL/SAT	Shift + CH+ /
CH Disc/Album- CBL/SAT	Shift + CH- /
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8
9 CBL/SAT	Shift + 9
Guide CBL/SAT	Shift + Guide / EPG / -/--
0/11 CBL/SAT	Shift + 0
Movie Tv/Search CBL/SAT	Shift + Red / Netflix /
Music/Repeat CBL/SAT	Shift + Green / APP / Repeat

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
RANDOM GAME C — Game/ Random	SHIFT + YouTube REPEAT A-B — Shift + Yellow / YouTube /		
MODE STEREO D — Stereo/ Mode	SHIFT + Prime Video RANDOM — Shift + Blue / Prime		

Originalfernbedienung	Ersatzfernbedienung
Power CD	Power
Play CD	Play / Slow
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
<< CD	<< / Tune-
>> CD	>> / Tune+
I << CD	I << / Preset-
>>I CD	>>I / Preset+
Audio CD	Audio / Lang I/II
Setup CD	Setup / OPT /
Up CD	Up
Left CD	Left
Enter CD	OK
Right CD	Right
Down CD	Down
Return CD	Back / Return
Vol + Receiver	Vol +

Originalfernbedienung	Ersatzfernbedienung
TV/CD	Smart / List
CH/Disc+ CD	CH+ / Page+
Vol - Receiver	Vol -
CH/Disc- CD	CH- / Page-
1 CD	1
2 CD	2
3 CD	3
4 CD	4
5 CD	5
6 CD	6
7 CD	7
8 CD	8
9 CD	9
+10/--/--10/D.Tun Dimmer CD	Guide / EPG / -/--
0/11 CD	0
CLR/Sleep/12	Fav / Marker / PC
Search CD	Red / Netflix / Search

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
REPEAT MUSIC B — Repeat CD	APP REPEAT — Green / APP / Repeat		
MODE STEREO D — Mode CD	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
RANDOM GAME C — Random CD	Prime Video RANDOM — Blue / Prime Video / Random		

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver Zone 2		Power
CH DISC	CH Disc/Album+ Zone 2	CH PAGE	CH+ / Page+
VOL	Vol + Zone 2	VOL	Vol +
ALBUM	CH Disc/Album Zone 2	CH PAGE	CH- / Page-
VOL	Vol - Zone 2	VOL	Vol -
	Up Zone 2		Up
PLAYLIST	Left Zone 2		Left
ENTER	Enter Zone 2	OK	OK
PLAYLIST	Right Zone 2		Right
SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /
	Down Zone 2		Down
RETURN	Return Zone 2	RETURN BACK	Back / Return
AUDIO HOME	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II
	I<< Zone 2	PRESET-	I<< / Preset-
	>>I Zone 2	PRESET+	>>I / Preset+
	<< Zone 2	TUNE-	<< / Tune-
	Play Zone 2	SLOW	Play / Slow

Originalfernbedienung		Ersatzfernbedienung	
	>> Zone 2	TUNE+	>> / Tune+
	Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
	Stop Zone 2	HOLD	Stop / Hold
SEARCH MOVIE/TV A	Movie Tv Zone	NETFLIX SEARCH	Red / Netflix / Search
REPEAT MUSIC B	Music Zone 2	APP REPEAT	Green / APP / Repeat
RANDOM GAME C	Game Zone 2	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MODE STEREO D	Stereo Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Zone 2	TV 1	1
2	2 Zone 2	DVD 2	2
3	3 Zone 2	CD-STB 3	3
4	4 Zone 2	VIDEO 4	4
5	5 Zone 2	TAPE 5	5
6	6 Zone 2	TUNER 6	6
7	7 Zone 2	AUX-HDD 7	7
8	8 Zone 2	USB 8	8
9	9 Zone 2	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
11 0 0/11 Zone 2	HDMI - SAT 0 0		
12 CLR SLEEP CLR/Sleep/12	PC FAV MARKER Fav / Marker / PC		