Originalfernbedienung		Ersatzfernbedienung	
ON	ON	Power	Power
STANDBY	Standby	SHIFT + Power	Shift + Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	BD / DVD	DVD 2	2
VCR/DVR	VCR / DVR	VIDEO 4	4
CBL/SAT	CBL / SAT	HDMI - SAT 0	0
GAME	GAME	BLUETOOTH 9	9
PC	PC	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
TUNER	TUNER	TUNER 6	6
TV/CD	TV/CD	TV 1	1
TV/CD	TV/CD	CD - STB 3	3
PHONO	PHONO	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
PORT	PORT	-/-- GUIDE EPG	Guide / EPG / -/--
NET/USB	NET	TAPE 5	5
NET/USB	USB	USB 8	8
MUTING	Muting	DIMMER MUTE	Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
CH DISC	CH+	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
DISC ALBUM	CH-	CH PAGE −	CH- / Page-
VOL	Vol -	VOL −	Vol -
GUIDE/TOP MENU SP LAYOUT	SP Layout	ANGLE INFO	Info / Angle
	Up		Up
PREV CH/MENU VIDEO	Menu	HOME MENU	Menu / Home
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
HOME	Home	TOP MENU D.MENU	D. Menu / Top
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Originalfernbedienung	Ersatzfernbedienung
Play	Play / Slow
>>	>> / Tune+
Pause / Play Rev	Pause / Step / Freeze
Stop	Stop / Hold
Listening Mode Movie / TV	Red / Netflix / Search
Listening Mode Music	Green / APP / Repeat
Listening Mode	Yellow / YouTube / Repeat
Listening Mode	Blue / Prime Video / Random
1	Shift + 1
2	Shift + 2
3	Shift + 3
4	Shift + 4
5	Shift + 5
6	Shift + 6
7	Shift + 7
8	Shift + 8
9	Shift + 9

Originalfernbedienung	Ersatzfernbedienung
0	Shift + 0
D.TUN	Smart / List
Dimmer	Shift + Mute / Dimmer
Sleep	Sleep / Timer

Originalfernbedienung		Ersatzfernbedienung	
ON	ON		Power
STANDBY	Standby	SHIFT +	Shift + Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	BD / DVD	DVD 2	2
VCR/DVR	VCR / DVR	VIDEO 4	4
CBL/SAT	CBL / SAT	HDMI - SAT 0	0
GAME	GAME	BLUETOOTH 9	9
PC	PC	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
TUNER	TUNER	TUNER 6	6
TV/CD	TV/CD	TV 1	1
TV/CD	TV/CD	CD - STB 3	3
PHONO	PHONO	SHIFT +	PC FAV MARKER Shift + Fav / Marker / PC
PORT	PORT	-/-- GUIDE EPG	Guide / EPG / -/--
NET/USB	NET	TAPE 5	5
NET/USB	USB	USB 8	8
MUTING	Muting	DIMMER MUTE	Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
CH DISC	CH+ / Album+	CH PAGE	CH+ / Page+
VOL	Vol +	VOL	Vol +
DISC ALBUM	CH- / Album	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -
GUIDE/TOP MENU SP LAYOUT	Top Menu	ANGLE INFO	Info / Angle
	Up		Up
PREV CH/MENU VIDEO	Menu	HOME MENU	Menu / Home
PLAYLIST /CATEGORY	Left / Playlist/Categor		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right / Playlist/Categor		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
HOME	Home	TOP MENU D.MENU	D. Menu / Top
	<<	PRESET-	<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Originalfernbedienung	Ersatzfernbedienung
Play	SLOW Play / Slow
>>	TUNE+ >> / Tune+
Pause / Play Rev	STEP-FREEZE Pause / Step / Freeze
Stop	HOLD Stop / Hold
MOVIE/TV SEARCH Search	NETFLIX SEARCH Red / Netflix / Search
MUSIC REPEAT Repeat	APP REPEAT Green / APP / Repeat
GAME RANDOM Random	Prime Video RANDOM Blue / Prime Video / Random
THX PLAY MODE Play Mode	YouTube REPEAT A-B Yellow / YouTube / Repeat
1	SHIFT + TV 1 Shift + 1
2	SHIFT + DVD 2 Shift + 2
3	SHIFT + CD-STB 3 Shift + 3
4	SHIFT + VIDEO 4 Shift + 4
5	SHIFT + TAPE 5 Shift + 5
6	SHIFT + TUNER 6 Shift + 6
7	SHIFT + AUX-HDD 7 Shift + 7
8	SHIFT + USB 8 Shift + 8
9	SHIFT + BLUETOOTH 9 Shift + 9

Originalfernbedienung	Ersatzfernbedienung
+10 D.TUN DIMMER --/--- +10	SHIFT + GUIDE EPG Shift + Guide / EPG / -/--
0	SHIFT + HDMI-SAT 0 Shift + 0
CLR SLEEP CLR	TIMER SLEEP Sleep / Timer