Originalfernbedienung		Ersatzfernbedienung	
POWER	Power	POWER	Power
SOUND IMAGE	Sound Image	TITLE SOUND	Sound / Title
FUNCTION	Function	HOME MENU	Menu / Home
VOLUME −	Volume-	VOL −	Vol -
VOLUME +	Volume+	+ VOL	Vol +
EFFECT	Effect	TOP MENU D.MENU	D. Menu / Top
GEQ	GEQ	LANG I/II AUDIO	Audio / Lang I/II
SMART EQ	Smart EQ	EQ SUBTITLE	Subtitle / EQ
FLAT	Flat	SIZE ZOOM	Zoom / Size
SURR & ST. WIDE	ST Wide	SURROUND ⏏	Eject / Surround
SOUND −	Sound Jog -	CH PAGE −	CH- / Page-
SOUND +	Sound Jog+	+ CH PAGE	CH+ / Page+
PGM BAND	CD PGM	PROGRAM TV/RADIO	TV/Radio /
PGM BAND	TUNER Band	ANGLE INFO	Info / Angle
RANDOM FM MONO	TUNER FM	MEDIA DISPLAY	Display / Media
RANDOM FM MONO	CD Random	Prime Video RANDOM	Blue / Prime Video / Random
SFC MODE	SFC Mode	NETFLIX SEARCH	Red / Netflix / Search

Originalfernbedienung		Ersatzfernbedienung	
PGM MODE	PGM Mode	APP REPEAT	Green / APP / Repeat
1/1	CD 1	TV 1	1
1/1	TUNER 1	SHIFT + TV 1	Shift + 1
2/2	CD 2	DVD 2	2
2/2	TUNER 2	SHIFT + DVD 2	Shift + 2
3/3	CD 3	CD-STB 3	3
3/3	TUNER 3	SHIFT + CD-STB 3	Shift + 3
4/4	CD 4	VIDEO 4	4
4/4	TUNER 4	SHIFT + VIDEO 4	Shift + 4
5/5	CD 5	TAPE 5	5
5/5	TUNER 5	SHIFT + TAPE 5	Shift + 5
6/6	CD 6	TUNER 6	6
6/6	TUNER 6	SHIFT + TUNER 6	Shift + 6
7/7	CD 7	AUX-HDD 7	7
7/7	TUNER 7	SHIFT + AUX-HDD 7	Shift + 7
8/8	CD 8	USB 8	8
8/8	TUNER 8	SHIFT + USB 8	Shift + 8

Originalfernbedienung		Ersatzfernbedienung	
9/9	CD 9	BLUETOOTH 9	9
9/9	TUNER 9	SHIFT + BLUETOOTH 9	Shift + 9
10/0/10	CD 10/0	HDMI - SAT 0	0
10/0/10	TUNER 10	SHIFT + HDMI - SAT 0	Shift + 0
>10/11	CD >10	-/-- GUIDE EPG	Guide / EPG / -/--
>10/11	TUNER 11	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
CLR/12	CD Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLR/12	TUNER 12	PC FAV MARKER	Fav / Marker / PC
DISC	CD Disc	REC MODE	Rec / Rec Mode
■	CD Stop	HOLD ■	Stop / Hold
❚❚	CD Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
▶	CD Play	SLOW ▶	Play / Slow
HI-LITE SCAN	TUNER Scan	LIST SMART	Smart / List
HI-LITE SCAN	CD Hi-Lite	FORMAT PICTURE	Picture / Format
⏮	CD I <<	PRESET- ⏮	I << / Preset-
⏮	Tuner Station	TUNE- ◀◀	<< / Tune-
⏭	CD >>I	PRESET+ ⏭	>>I / Preset+

Originalfernbedienung		Ersatzfernbedienung	
⏭	Tuner Station	TUNE+ ▶▶	>> / Tune+
DEC ◀	TAPE1 Rev. Play	◀	Left
CK I ▶	TAPE1 Play	▶	Right
DEC ◀	TAPE2 Rev. Play	SHIFT + ◀	Shift + Left
CK II ▶	TAPE2 Play	SHIFT + ▶	Shift + Right
◀◀	TAPE1 <<	▼	Down
▶▶	TAPE1 >>	▲	Up
◀◀	TAPE2 <<	SHIFT + ▼	Shift + Down
▶▶	TAPE2 >>	SHIFT + ▲	Shift + Up
■	TAPE1 Stop	OK	OK
●	TAPE2 Rec	SHIFT + REC MODE ●	Shift + Rec / Rec Mode
❚❚	TAPE2 Pause	SHIFT + RETURN BACK	Shift + Back / Return
■	TAPE2 Stop	SHIFT + OK	Shift + OK
WAKE-UP	Wake-Up	GOTO TEXT	Text / Goto
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER SNOOZE	Timer Snooze	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
TIMER SNOOZE	Timer Snooze	DIMMER MUTE	Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power	POWER	Power
SOUND IMAGE	Sound Image	TITLE SOUND	Sound / Title
FUNCTION	Function	HOME MENU	Menu / Home
VOLUME −	Volume-	VOL −	Vol -
VOLUME +	Volume+	+ VOL	Vol +
EFFECT	Effect	TOP MENU D.MENU	D. Menu / Top
GEQ	GEQ	LANG I/II AUDIO	Audio / Lang I/II
SMART EQ	Smart EQ	EQ SUBTITLE	Subtitle / EQ
SURR & ST WIDE	ST Wide	SURROUND ⏏	Eject / Surround
SOUND −	Sound Jog -	CH PAGE −	CH- / Page-
FLAT	Flat	SIZE ZOOM	Zoom / Size
SOUND JOG +	Sound Jog+	+ CH PAGE	CH+ / Page+
PGM BAND	CD PGM	PROGRAM TV/RADIO	TV/Radio /
PGM BAND	TUNER Band	ANGLE INFO	Info / Angle
RANDOM FM MONO	TUNER FM	MEDIA DISPLAY	Display / Media
RANDOM FM MONO	CD Random	Prime Video RANDOM	Blue / Prime Video / Random
SFC MODE	SFC Mode	NETFLIX SEARCH	Red / Netflix / Search

Originalfernbedienung		Ersatzfernbedienung	
PGM MODE	PGM Mode	APP REPEAT	Green / APP / Repeat
1/1	CD 1	TV 1	1
1/1	TUNER 1	SHIFT + TV 1	Shift + 1
2/2	CD 2	DVD 2	2
2/2	TUNER 2	SHIFT + DVD 2	Shift + 2
3/3	CD 3	CD-STB 3	3
3/3	TUNER 3	SHIFT + CD-STB 3	Shift + 3
4/4	CD 4	VIDEO 4	4
4/4	TUNER 4	SHIFT + VIDEO 4	Shift + 4
5/5	CD 5	TAPE 5	5
5/5	TUNER 5	SHIFT + TAPE 5	Shift + 5
6/6	CD 6	TUNER 6	6
6/6	TUNER 6	SHIFT + TUNER 6	Shift + 6
7/7	CD 7	AUX-HDD 7	7
7/7	TUNER 7	SHIFT + AUX-HDD 7	Shift + 7
8/8	CD 8	USB 8	8
8/8	TUNER 8	SHIFT + USB 8	Shift + 8

Originalfernbedienung		Ersatzfernbedienung	
9/9	CD 9	BLUETOOTH 9	9
9/9	TUNER 9	SHIFT + BLUETOOTH 9	Shift + 9
10/0/10	CD 10/0	HDMI - SAT 0	0
10/0/10	TUNER 10	SHIFT + HDMI - SAT 0	Shift + 0
>10/11	CD >10	-/-- GUIDE EPG	Guide / EPG / -/--
>10/11	TUNER 11	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
CLR/12	CD Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CLR/12	TUNER 12	PC FAV MARKER	Fav / Marker / PC
DISC	CD Disc	REC MODE	Rec / Rec Mode
■	CD Stop	HOLD ■	Stop / Hold
❚❚	CD Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
▶	CD Play	SLOW ▶	Play / Slow
HI-LITE SCAN	TUNER Scan	LIST SMART	Smart / List
HI-LITE SCAN	CD Hi-Lite	FORMAT PICTURE	Picture / Format
⏮	CD I <<	PRESET- ⏮	I << / Preset-
⏮	Tuner Station	TUNE- ◀◀	<< / Tune-
⏭	CD >>I	PRESET+ ⏭	>>I / Preset+

Originalfernbedienung		Ersatzfernbedienung	
⏭	Tuner Station	TUNE+ ▶▶	>> / Tune+
DEC ◀	TAPE1 Rev. Play	◀	Left
CK I ▶	TAPE1 Play	▶	Right
DEC ◀	TAPE2 Rev. Play	SHIFT + ◀	Shift + Left
CK II ▶	TAPE2 Play	SHIFT + ▶	Shift + Right
◀◀	TAPE1 <<	▼	Down
▶▶	TAPE1 >>	▲	Up
◀◀	TAPE2 <<	SHIFT + ▼	Shift + Down
▶▶	TAPE2 >>	SHIFT + ▲	Shift + Up
■	TAPE1 Stop	OK	OK
●	TAPE2 Rec	SHIFT + REC MODE ●	Shift + Rec / Rec Mode
❚❚	TAPE2 Pause	SHIFT + RETURN BACK	Shift + Back / Return
■	TAPE2 Stop	SHIFT + OK	Shift + OK
WAKE-UP	Wake-Up	GOTO TEXT	Text / Goto
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER SNOOZE	Timer Snooze	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
TIMER SNOOZE	Timer Snooze	DIMMER MUTE	Mute / Dimmer