Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<	PRESET-	I<< / Preset-
	>I	PRESET+	>>I / Preset+
LIVING SOUND	Living Sound	LANG I/II AUDIO	Audio / Lang I/II
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	Timer On/Off	PROGRAM TV/RADIO	TV/Radio /
CLOCK SET	Clock Set	HOME MENU	Menu / Home
VOL +	Vol +	VOL +	Vol +
DBB	DBB	LIST SMART	Smart / List
ALBUM +	Album+	CH PAGE +	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung	
VOL -	Vol -	VOL -	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
ALBUM -	Album-	CH PAGE -	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
PROG	Prog	SHIFT	+ PROGRAM TV/RADIO Shift + TV/Radio / Program				
DSC	DSC	SHIFT	+ MEDIA DISPLAY Shift + Display / Media				

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<	PRESET-	I<< / Preset-
	>I	PRESET+	>>I / Preset+
LIVING SOUND	Living Sound	LANG I/II AUDIO	Audio / Lang I/II
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	Timer On/Off	PROGRAM TV/RADIO	TV/Radio /
CLOCK SET	Clock Set	HOME MENU	Menu / Home
VOL +	Vol +	VOL +	Vol +
DBB	DBB	LIST SMART	Smart / List
ALBUM +	Album+	CH PAGE +	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung	
VOL -	Vol -	VOL -	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
ALBUM -	Album-	CH PAGE -	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer

Originalfernbedienung		Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
PROG	Prog	SHIFT + PROGRAM TV/RADIO Shift + TV/Radio / Program		
DSC	DSC	SHIFT + MEDIA DISPLAY Shift + Display / Media		

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<	PRESET-	I<< / Preset-
	>I	PRESET+	>>I / Preset+
LIVING SOUND	Living Sound	LANG I/II AUDIO	Audio / Lang I/II
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	Timer On/Off	PROGRAM TV/RADIO	TV/Radio /
RDS	RDS	RDS AV INPUT	AV / Input / RDS
CLOCK SET	Clock Set	HOME MENU	Menu / Home
VOL +	Vol +	VOL +	Vol +
DBB	DBB	LIST SMART	Smart / List
VOL -	Vol -	VOL -	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1

Originalfernbedienung		Ersatzfernbedienung	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
PROG	Prog	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
DSC	DSC	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
■	Stop	HOLD ■	Stop / Hold
LIVING SOUND	Living Sound	LANG I/II AUDIO	Audio / Lang I/II
OPEN/CLOSE	Open/Close	SURROUND ⏏	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	Timer On/Off	PROGRAM TV/RADIO	TV/Radio /
CLOCK SET	Clock Set	HOME MENU	Menu / Home
+ VOL	Vol +	+ VOL	Vol +
DBB	DBB	LIST SMART	Smart / List
VOL −	Vol -	VOL −	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5

Originalfernbedienung		Ersatzfernbedienung	
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TIMER	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
DSC	DSC	SHIFT + MEDIA DISPLAY	Shift + Display / Media