Originalfernbedienung	Ersatzfernbedienung
Muting Receiver	Mute
Power Receiver	Power
Display	Info
Enter Receiver	Ok
Up Receiver	Up
Down Receiver	Down
Right Receiver	Right
Left Receiver	Left
Return Receiver	Back
Setup Receiver	Smart
Audio/Home	Media
Play Receiver	Play
I<< Receiver	I<<
>>I Receiver	>>I
<< Receiver	<<
>> Receiver	>>
Pause/Play reverse Receiver	Pause

Originalfernbedienung	Ersatzfernbedienung
Stop Receiver	Stop
1 Receiver	1
2 Receiver	2
3 Receiver	3
4 Receiver	4
5 Receiver	5
6 Receiver	6
7 Receiver	7
8 Receiver	8
9 Receiver	9
0/11 Receiver	0
+10/---/---10/Dimer/D.Tun Receive	Shift + Guide
CLR/Sleep/12 Receiver	Pre Ch
Movie Tv/Search Receiver	Red
Music/Repeat Receiver	Green
Game/Random Receiver	Yellow
THX/Play Mode Receiver	Blue

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL –	Vol -
CH DISC	CH/Disc/Album+ Receiver	+ CH	Ch +
ALBUM	CH/Disc/Album Receiver	CH –	Ch -
TV	Power Tv	SHIFT +	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH DISC	CH+ Tv	SHIFT + + CH	Shift + Ch +
ALBUM	CH- Tv	SHIFT + CH –	Shift + Ch -
	Up Tv	SHIFT +	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT +	Shift + Down
PLAYLIST	Right Tv	SHIFT +	Shift + Right
PLAYLIST	Left Tv	SHIFT +	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Guide/Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Setup Tv	SHIFT + HOME SMART	Shift + Smart

Originalfernbedienung		Ersatzfernbedienung	
SEARCH MOVIE/TV A	Movie/TV/Search	SETTINGS OPT	Options
REPEAT MUSIC B	Music/Repeat	SOUND DUAL	Dual
RANDOM GAME C	Game/Random	AD SUBT	Subt
MODE THX D	Stereo/Play Mode	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
10 +10 D.TUN DIMMER	+10/--/--10 Tv	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
VOL Vol - Tv	SHIFT + SETTINGS OPT Shift + Options		
AUX AUX	REPEAT TEXT Text		
TV/CD TV / CD	PICTURE FORMAT Format		
CBL/SAT CBL/SAT	ECO 3D 3D		
FM FM	SHIFT + AD SUBT Shift + Subt		
BD/DVD DVD / BD	SHIFT + REPEAT TEXT Shift + Text		
GAME Game	SHIFT + SEARCH TV/R Shift + TV/R		
STB/DVR VCR / DVR	SHIFT + TIMER AV Shift + AV		
PC PC	ZOOM ⏏ Eject		
USB USB	DISC NAV LIST List		
NET NET	SHIFT + ZOOM ⏏ Shift + Eject		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Setup BD/DVD	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
PLAYLIST	Right BD/DVD		Right
PLAYLIST	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
	Play BD/DVD	PLAY MODE	Play
	Pause/Play rev. BD/DVD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Search BD/DVD	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Originalfernbedienung		Ersatzfernbedienung	
CBL/SAT	CBL/SAT	REPEAT TEXT	Text
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL −	Vol -
SOURCE	Power CBL/SAT	SHIFT +	Shift + Power
CH DISC	CH Disc/Album+ CBL/SAT	+ CH	Ch +
ALBUM	CH Disc/Album- CBL/SAT	CH −	Ch -
MENU PREV CH	Menu/Prev CH CBL/SAT	SHIFT +	Shift + Menu
TOP MENU GUIDE	Top Menu/Guide CBL/SAT	SHIFT + SETTINGS OPT	Shift + Options
RETURN	Return CBL/SAT	SHIFT + RETURN BACK	Shift + Back
SETUP	Setup CBL/SAT	SHIFT + HOME SMART	Shift + Smart
	Up CBL/SAT	SHIFT +	Shift + Up
ENTER	Enter CBL/SAT	SHIFT + OK	Shift + Ok
	Down CBL/SAT	SHIFT +	Shift + Down
PLAYLIST	Right CBL/SAT	SHIFT +	Shift + Right
PLAYLIST	Left CBL/SAT	SHIFT +	Shift + Left
	Pause/Play rev. CBL/SAT	SHIFT +	Shift + Pause
	Stop CBL/SAT	SHIFT +	Shift + Stop

Originalfernbedienung		Ersatzfernbedienung	
	<< CBL/SAT	SHIFT + CH −	Shift + Ch -
	>> CBL/SAT	SHIFT + + CH	Shift + Ch +
	Play CBL/SAT	ECO 3D	3D
SEARCH MOVIE/TV A	Movie Tv/Search CBL/SAT	SOUND DUAL	Dual
REPEAT MUSIC B	Music/Repeat CBL/SAT	AD SUBT	Subt
RANDOM GAME C	Game/Random	TIMER AV	AV
MODE THX D	Stereo/Play Mode CBL/SAT	PICTURE FORMAT	Format
1	1 CBL/SAT	SHIFT + 1	Shift + 1
2	2 CBL/SAT	SHIFT + 2	Shift + 2
3	3 CBL/SAT	SHIFT + 3	Shift + 3
4	4 CBL/SAT	SHIFT + 4	Shift + 4
5	5 CBL/SAT	SHIFT + 5	Shift + 5
6	6 CBL/SAT	SHIFT + 6	Shift + 6
7	7 CBL/SAT	SHIFT + 7	Shift + 7
8	8 CBL/SAT	SHIFT + 8	Shift + 8
9	9 CBL/SAT	SHIFT + 9	Shift + 9
11 0	0/11 CBL/SAT	SHIFT + 0	Shift + 0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
BD/DVD DVD/ BD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power CD		Power
CH DISC +	CH/Disc+ CD	CH +	Ch +
ALBUM −	CH/Disc- CD	CH −	Ch -
RETURN	Return CD	RETURN BACK	Back
SETUP	Setup CD	HOME SMART	Smart
AUDIO HOME	Home/Audio CD	APP MEDIA	Media
	Up CD		Up
	Down CD		Down
PLAYLIST	Right CD		Right
PLAYLIST	Left CD		Left
ENTER	Enter CD	OK	Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD	PLAY MODE	Play
	Pause CD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop CD		Stop
SEARCH MOVIE/TV A	Movie Tv/Search	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode	D	Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
11 0	0/11 CD	0	0
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
VOL Vol + Recei ver	+ VOL Vol +		
VOL Vol - Recei ver	VOL – Vol -		
TV/CD TV/ CD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL +	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
PLAYLIST	Right Zone 2		Right
PLAYLIST	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
SETUP	Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Audio Zone 2	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Originalfernbedienung		Ersatzfernbedienung	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Search Zone 2	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
11 0	0/11 Zone 2	0	0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		