Originalfernbedienung		Ersatzfernbedienung	
VTR	VTR		Power
TRANSMIT	Transmit	LIST SMART	Smart / List
PAUSE/STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
STILL ADV	Still Adv	Prime Video RANDOM	Blue / Prime Video / Random
REW/	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
/FF	>>	TUNE+	>> / Tune+
REC	Rec	REC MODE	Rec / Rec Mode
-	-		Left
SLOW	Slow	OK	OK
+	+		Right
CLOCK/ COUNTER	Clock/Counter	PC FAV MARKER	Fav / Marker / PC
TAPE REMAIN	Tape Remain	MEDIA DISPLAY	Display / Media
RESET	Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MONITOR	Monitor	TOP MENU D.MENU	D. Menu / Top
VTR/TV	VTR/TV	PROGRAM TV/ RADIO	TV/Radio / Program

Originalfernbedienung		Ersatzfernbedienung	
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
INDEX	Index	ANGLE INFO	Info / Angle
TIME SEARCH	Time Search	NETFLIX SEARCH	Red / Netflix / Search
TRACKING/V-	Tracking/V-Lock-	CH PAGE -	CH- / Page-
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
MEMORY	Memory	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
REWIND	Rewind	RETURN BACK	Back / Return
AUDIO OUT	Audio Out	LANG I/II AUDIO	Audio / Lang I/II
SU 1	1	TV 1	1
MO 2	2	DVD 2	2
TU 3	3	CD-STB 3	3
WE 4	4	VIDEO 4	4
TH 5	5	TAPE 5	5
FR 6	6	TUNER 6	6
	Recording SP/LP	FORMAT PICTURE	Picture / Format

Originalfernbedienung	Ersatzfernbedienung
7	7
8	8
9	9
0	0
-/--	Guide / EPG / -/--
Timer Rec	Shift + Sleep / Timer
Pal / Mesecam	Zoom / Size

Originalfernbedienung	Ersatzfernbedienung