Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
STANDBY	Standby	SHIFT +	Shift + Power	VOL –	Volume-	VOL –	Vol -
SYSTEM POWER	Power		Power	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	LEVEL TITLE	Title/Level	TITLE SOUND	Sound / Title
PHONO	Phono	SHIFT +	PC FAV MARKER Shift + Fav / Marker / PC	▲	Up / Preset/CH+	▲	Up
TUNER	Tuner	SHIFT +	TUNER 6 Shift + 6	SET MENU MENU	Menu/Set Menu	HOME MENU	Menu / Home
CD	CD	SHIFT +	CD-STB 3 Shift + 3	PURE DIRECT	Pure Direct	FORMAT PICTURE	Picture / Format
MULTI CH IN	Multi CH In	PC FAV MARKER	Fav / Marker / PC	◄	Left / A/B/C/D/E	◄	Left
V-AUX	V-AUX	SHIFT +	AUX-HDD 7 Shift + 7	ENTER	Enter	OK	OK
CBL/SAT	CBL/SAT	SHIFT +	HDMI-SAT 0 Shift + 0	►	Right /	►	Right
MD/TAPE	MD/TAPE	SHIFT +	TAPE 5 Shift + 5	NIGHT AUDIO	Night	SHIFT +	TIMER SLEEP Shift + Sleep / Timer
CD-R	CD-R	SHIFT +	BLUETOOTH 9 Shift + 9	NIGHT AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
DTV	DTV	SHIFT +	TV 1 Shift + 1	TEST RETURN	Return	RETURN BACK	Back / Return
VCR 1	VCR 1	SHIFT +	VIDEO 4 Shift + 4	▼	Down / Preset/CH-	▼	Down
DVR/VCR2	DVR	SHIFT +	USB 8 Shift + 8	ON SCREEN DISPLAY	Display	MEDIA DISPLAY	Display / Media
DVR/VCR2	VCR 2	SHIFT +	-/-- GUIDE EPG Shift + Guide / EPG / -/--	STRAIGHT EFFECT	Straight	SIZE ZOOM	Zoom / Size
DVD	DVD	SHIFT +	DVD 2 Shift + 2	STEREO 1	STEREO	TV 1	1
+ VOL	Volume+	+ VOL	Vol +	HALL 2	HALL	DVD 2	2

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
JAZZ 3	JAZZ	CD-STB 3	3		
ROCK 4	ROCK	VIDEO 4	4		
ENTERTAIN 5	ENTERTAIN	TAPE 5	5		
MUSIC 6	MUSIC	TUNER 6	6		
TV THTR 7	TV THTR	AUX-HDD 7	7		
MOVIE 8	MOVIE	USB 8	8		
THX 9	THX	BLUETOOTH 9	9		
EXTD SUR. ENT.	Extd. Sur.	SURROUND	Eject / Surround		
FREQ/RDS	<</ Freq/RDS	TUNE-	<< / Tune-		
EON	>>/ Eon	TUNE+	>> / Tune+		
MODE – PTY	I <</ Mode PTY	PRESET-	I << / Preset-		
SEEK – START	>>I / PTY Seek	PRESET+	>>I / Preset+		

Originalfernbedienung		Ersatzfernbedienung	
SYSTEM POWER	Power		Power
PRESET + CH	Preset Up	PRESET+	>>I / Preset +
PRESET + CH	Preset Up	CH PAGE +	CH+ / Page+
+ VOL	Vol +	+ VOL	Vol +
CH − A/B/C/D/E	Preset Down	PRESET-	I << / Preset -
CH − A/B/C/D/E	Preset Down	CH PAGE −	CH- / Page-
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
◄	Left A/B/C/D/E	◄	Left
ENTER	Enter	OK	OK
►	Right A/B/C/D/	►	Right
ON SCREEN DISPLAY	Display	MEDIA DISPLAY	Display / Media
STEREO 1	1	TV 1	1
HALL 2	2	DVD 2	2
JAZZ 3	3	CD - STB 3	3
ROCK 4	4	VIDEO 4	4
ENTERTAIN 5	5	TAPE 5	5

Originalfernbedienung		Ersatzfernbedienung	
MUSIC 6	6	TUNER 6	6
TV THTR 7	7	AUX - HDD 7	7
MOVIE 8	8	USB 8	8
THX 9	9	BLUETOOTH 9	9
STANDARD 0	0	HDMI - SAT 0	0
EXTD SUR. ENT.	ENT	PC FAV MARKER	Fav / Marker / PC
FREQ/RDS ◄◄	Freq/RDS	RDS AV INPUT	AV / Input / RDS
EON ►►	Eon	TOP MENU D.MENU	D.Menu / Top
MODE – PTY S ◄◄	Mode PTY Seek	GOTO TEXT	Text / Goto
Y SEEK – START ►►	PTY Seek Start	OPT-TOOLS SETUP	Setup / OPT /

Originalfernbedienung		Ersatzfernbedienung	
POWER AV	Power		Power
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
LEVEL TITLE	Title	TITLE SOUND	Sound / Title
▲	Up	▲	Up
SET MENU MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
NIGHT AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
TEST RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
ON SCREEN DISPLAY	Display	MEDIA DISPLAY	Display / Media
STEREO 1	1	TV 1	1
HALL 2	2	DVD 2	2
JAZZ 3	3	CD-STB 3	3

Originalfernbedienung		Ersatzfernbedienung	
ROCK 4	4	VIDEO 4	4
ENTERTAIN 5	5	TAPE 5	5
MUSIC 6	6	TUNER 6	6
TV THTR 7	7	AUX-HDD 7	7
MOVIE 8	8	USB 8	8
THX 9	9	BLUETOOTH 9	9
STANDARD 0	0	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
EXTD SUR. ENT.	ENT	PC FAV MARKER	Fav / Marker / PC
FREQ/RDS ◀◀	<<	TUNE- ◀◀	<< / Tune-
EON ▶▶	>>	TUNE+ ▶▶	>> / Tune+
MODE – PTY S ⏮	I <<	PRESET- ⏮	I << / Preset-
Y SEEK – START ⏭	>>I	PRESET+ ⏭	>>I / Preset+
REC DISC SKIP	Rec	REC MODE	Rec / Rec Mode
■	Stop	HOLD ■	Stop / Hold
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow