Originalfernbedienung		Ersatzfernbedienung	
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Power		Power
SPEAKERS A	Speakers A	TITLE SOUND	Sound / Title
SPEAKERS B	Speakers B	LANG I/II AUDIO	Audio / Lang I/II
OPTICAL	Optical	TV 1	1
COAXIAL	Coaxial	DVD 2	2
CD	CD	CD-STB 3	3
LINE 1	Line 1	VIDEO 4	4
LINE 2	Line 2	TAPE 5	5
PHONO	Phono	AUX-HDD 7	7
TUNER	Tuner	TUNER 6	6
NET	Net	USB 8	8
BLUETOOTH	Bluetooth	BLUETOOTH 9	9
BAND	Band	LIST SMART	Smart / List
TUNING	<< Tuning	SHIFT + TUNE-	Shift + << /
TUNING	Tuning >>	SHIFT + TUNE+	Shift + >> / Tune+

Originalfernbedienung		Ersatzfernbedienung	
MEMORY	Memory	REC MODE	Rec / Rec Mode
PRESET	< Preset	CH PAGE –	CH- / Page-
PRESET	< Preset	SHIFT + PRESET-	Shift + I<< / Preset-
PRESET	Preset >	+ CH PAGE	CH+ / Page+
PRESET	Preset >	SHIFT + PRESET+	Shift + >>I / Preset+
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MODE	Mode	FORMAT PICTURE	Picture / Format
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
HOME	Home	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
VOLUME	Volume+	+ VOL	Vol +

Originalfernbedienung		Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools	
NOW PLAYING	Now Playing	-/-- GUIDE EPG	Guide / EPG / -/--	
VOLUME	Volume-	VOL –	Vol -	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat	
▷/DD	Play	SLOW ▶	Play / Slow	
▷/DD	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze	
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random	
⏮/◁◁	I <<</ <<	TUNE- ◀◀	<< / Tune-	
⏮/◁◁	I <<</ <<	PRESET- ⏮	I << / Preset-	
▭	Stop	HOLD ■	Stop / Hold	
▷▷/▷▷I	>>/ >>I	TUNE+ ▶▶	>> / Tune+	
▷▷/▷▷I	>>/ >>I	PRESET+ ⏭	>>I / Preset+	