Original	Replacement
Power	Power
OK	OK
Up	UP
Down	DOWN
Right	RIGHT
Left	LEFT
Return	BACK
Play	Play
Pause	Pause
Extra	MEDIA
Mute	MUTE
Vol+	VOL +
Vol-	VOL -
Guide	-/-- / EPG
CH+	CH +
CH-	CH -
Home	VOD

Original	Replacement
Source	SRC
TTX/MIX	TEXT
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
PRE-CH	P/C / FAV
Exit	EXIT
Info	INFO
Menu	MENU
Red	Red (A)

Original	Replacement	Original	Replacement
Green	Green (B)		
Yellow	Yellow (C)		
Blue	Blue (D)		
123	TV/R		
Tools	OPT+		
Stop	Stop		
Rec	Rec		
<<|<<	Rewind		
>>|>>|	Fast Forward		
CH List	WIDE		
AD/Subt.	Subt.		
E-Manual	Audio		