Original	Replacement	Original	Replacement
Power	Power	0	0
Mute	Mute	-/--/EXIT	-/--
Up	Up	-/--/EXIT	Exit
Down	Down	P<P/SWAP	P<P/Swap
Right	Right	Vol +	Vol +
Left	Left	Vol -	Vol -
OK/SELECT	Ok	P+	Ch +
M	Menu	P-	Ch -
1/ABC	1	PP	Eject
2/DEF	2	I-II	I-II
3/GHI	3	TV/DTV	TV/R
4/JKL	4	[≡]	Text
5/MNO	5	[≡O]	Options
6/PQR	6	AV/SOURCE	AV
7/STU	7	[≡+] / [X]	Format
8/VWX	8	[≡X] / [■■]	3D
9/YZ	9	[.≡] / [■]	Subt

Original		Replacement		Original		Replacement	
	[≡♦]		Medi a				
	[≡?]		Back				
	[≡i]		I nf o				
	Red/ [+] / Wi de/ ↑		Red				
	Gr een/ ↓		Gr een				
	Yel l ow		Yel l ow				
	Bl ue/ Gui de		Bl ue				
	[i]		D. Menu				