Original		Replacement	
	Power		Power
NETFLIX	Netfix	SHIFT +	NETFLIX SEARCH — Shift + Red / Netflix /
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
0	0	HDMI - SAT 0	0
	Recall	PC FAV MARKER	Fav / Marker / PC
V+	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P+	PR+	+ CH PAGE	CH+ / Page+

Original		Replacement	
V-	Vol -	VOL –	Vol -
i	i	ANGLE INFO	Info / Angle
P-	PR-	CH PAGE –	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
Q. MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
BACK	Back	RETURN BACK	Back / Return
▼	Down	▼	Down
EXIT	EXit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	World	LIST SMART	Smart / List
	Camera/Music/Ph	MEDIA DISPLAY	Display / Media
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	*/o	FORMAT PICTURE	Picture / Format
	Games	RDS AV INPUT	AV / Input / RDS

Original	Replacement	Original	Replacement
[≡] / Text	GOTO TEXT — Text / Goto		
Red	NETFLIX SEARCH — Red / Netflix / Search		
Green	APP REPEAT — Green / APP / Repeat		
Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM — Blue / Prime Video / Random		
LANG.	LANG I/II AUDIO — Audio / Lang I/II		
[≡]. .	EQ SUBTITLE — Subtitle / EQ		
[- O-]	SIZE ZOOM — Zoom / Size		
<<	TUNE- << — << / Tune-		
Pause	STEP-FREEZE ⏸ — Pause / Step / Freeze		
>>	TUNE+ >> — >> / Tune+		
Rec	REC MODE ● — Rec / Rec Mode		
Play	SLOW ▶ — Play / Slow		
Stop	HOLD ■ — Stop / Hold		