Original		Replacement	
On/Standby		Power	
Vol +		Vol +	
Vol -		Vol -	
1		1	
2		2	
3		3	
4		4	
5		5	
7		7	
6		6	
8		8	
9		9	
0		0	
+10		Guide	
CD		Red	
Tuner (Band)		Green	
Tape (1-2)		Yellow	

Original		Replacement	
Game/Video		Blue	
Memory		Rec	
Play CD		Play	
Stop CD		Stop	
Pause CD		Pause	
Random CD		Media	
Clear/Dimmer		Exit	
Play Tape		Smart	
Stop Tape		Shift + Stop	
Rec/Pause Tape		Shift + Pause	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
Enter		Ok	
Display		Info	
Navigator		Menu	

Original	Replacement
CHARACTER Character	RETURN BACK Back
CLOCK / TIMER Clock/Timer	TIMER AV AV
SET >>I / >>/ Up	+ CH Ch +
PR I <</ <</ Down	CH − Ch -
EQUALIZER MODE Equalizer Mode	SOUND DUAL Dual
X-BASS (SURROUND) X-Bass/Surroun	AD SUBT Subt
DISC SELECT 1 Select Drive 1	SHIFT + 1 Shift + 1
2 Select Drive 2	SHIFT + 2 Shift + 2
3 Select Drive 3	SHIFT + 3 Shift + 3
4 Select Drive 4	SHIFT + 4 Shift + 4
5 Select Drive 5	SHIFT + 5 Shift + 5

Original	Replacement