Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
ASPECT	Aspect	PICTURE FORMAT	Format
AUDIO	I / II / Audio	SOUND DUAL	Dual
REC	Rec	REC MODE	Rec
REC MENU	Rec Menu	E-MANUAL D.MENU	D. Menu
SLEEP	Sleep	PROG SLEEP	Sleep
EPG	EPG	-/-- GUIDE	Guide
FAV	FAV	FAV PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
0	0	0	0
TV/RADIO	Tv/ Radio	SEARCH TV/R	TV/ R
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
REPEAT	Recall / Repeat	RETURN BACK	Back
SOURCE	Source	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
P.MODE	P. Mode	SHIFT + PICTURE FORMAT	Shift + Format
S.MODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
CH+	CH+	+ CH	Ch +

Original		Replacement	
	CH-	CH –	Ch -
EXIT	Exit	CLEAR EXIT	Exit
DISPLAY	Display	DISPLAY INFO	Info
	Red/Eject	A	Red
SETUP	Green/Setup	B	Green
D.MENU	Yellow/D. Menu	C	Yellow
TITLE	Blue/Title	D	Blue
PROG TXT	TXT/Prog	REPEAT TEXT	Text
GOTO INDEX	Index/Goto	HOME SMART	Smart
A-B HOLD	Hold/A-B	ECO 3D	3D
SUB-T REVEAL	Reveal / Subt - T	AD SUBT	Subt
ZOOM SIZE	Size/Zoom	ZOOM	Eject
ANGLE SUBPG	Subpg/Angle	APP MEDIA	Media
	Play	PLAY MODE	Play
	Stop		Stop
	<<		<<
	>>		>>

Original		Replacement	
	I <<		I <<
	>>I		>>I