

Original		Replacement	
STANDBY ON/OFF	Standby		Power
OPEN/ CLOSE	Open/Close	ZOOM ⏏	Eject
KEY LOCK	Key Lock	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
DIGEST	Digest	HOME SMART	Smart
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
AUDIO MODE	Audio Mode	SOUND DUAL	Dual

Original		Replacement	
ZOOM	Zoom	SHIFT + ZOOM ⏏	Shift + Eject
TITLE MENU	Title Menu	TOP MENU MENU	Menu
SUBTITLE MENU	Subtitle Menu	AD SUBT	Subt
AUDIO MENU	Audio Menu	APP MEDIA	Media
PBC	PBC	C	Yellow
3D	3D	ECO 3D	3D
ANGLE	Angle	SEARCH TV/R	TV/R
DISPLAY	Display	DISPLAY INFO	Info
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
ENTER	Enter	OK	Ok
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
BOOKMARK	Bookmark	PICTURE FORMAT	Format
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R





Original		Replacement		Original	Replacement
PROGRAM	Program	PROG SLEEP	Sleep		
SLOW/F	Slow/F	-/-- GUIDE	Guide		
SLOW/R	Slow/R	FAV PRE-CH	Pre Ch		
▶	Play	PLAY MODE ▶	Play		
■	Stop	■	Stop		
▶▶I	>>I	⏭	>>I		
I◀◀	I<<	⏮	I<<		
▶▶	>>	⏩	>>		
◀◀	<<	⏪	<<		
PAUSE/ STEP	Pause/Step	⏸	Pause		
RANDOM	Random	D	Blue		
MUTE	Mute	MUTE	Mute		
REPEAT	Repeat	REPEAT TEXT	Text		
A-B	A-B	DISC NAV LIST	List		

