Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
TXT	TXT	REPEAT TEXT	Text
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original		Replacement	
GUIDE	Guide	GUIDE	Guide
?	?	PICTURE FORMAT	Format
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
BACK	Back	RETURN BACK	Back
TOOLS	Tools	SETTINGS OPT	Options
@	@	HOME SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
	Source	TIMER AV	AV
+ P	P +	+ CH	Ch +

Original		Replacement	
P -	P -	CH –	Ch -
I <	I <		I <<
PIP >I	>I / PI P	>>I	>>I
<<	<<	<<	<<
>>	>>	>>	>>
Rec	Rec	REC MODE	Rec
Pl ay	Pl ay	PLAY MODE	Pl ay
Pause	Pause	II	Pause
St op	St op	■	St op
3D	3D	ECO 3D	3D
QO. .	QO. .	SOUND DUAL	Dual
[. . .] . .	[. . .] . .	AD SUBT	Subt
NETFLIX	Net f l i x	SHIFT + APP MEDIA	Shi f t + Medi a
MY MEDIA	My Medi a	APP MEDIA	Medi a

Original	Replacement