Original		Replacement	
	Power		Power
	Select Drive		List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last View		Pre Ch
	Radio/Tv		TV/R
	CH/Page+		Ch +
	CH/Page-		Ch -
	Internet		Smart

Original		Replacement	
	Netflix		Media
	I<< Skip		I<<
	Skip >>I		>>I
	<< Slow/Search		<<
	Slow/Search >>		>>
	Stop		Stop
	Pause/Pause Live		Pause
	Play		Play
	Rec		Rec
	i/Status		Info
	X/Exit		Exit
	Video Menu		D. Menu
	Guide		Guide
	Function Menu		Menu
	Option		Options
	Return		Back
	Up		Up

Original		Replacement	
	Down		Down
	Right / II >		Right
	<II / Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
TEXT	Text	REPEAT TEXT	Text
STTL	STTL	AD SUBT	Subt
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
CHAPTER	Chapter	PICTURE FORMAT	Format
TIME SLIP	Time Slip	ECO 3D	3D
AUDIO	Audio	SOUND DUAL	Dual
INPUT SELECT	Input Select	TIMER AV	AV
DELETE	Delete	ZOOM	Eject

Original		Replacement	
MANUAL -10s	Manual Skip -10s	SHIFT +	Shift + Left
MANUAL SKIP +60s	Manual Skip +60s	SHIFT +	Shift + Right
TV	Power Tv	SHIFT +	Shift + Power
INPUT AV	AV Input Tv	SHIFT + TIMER AV	Shift + AV
VOL +	Vol + Tv	VOL +	Vol +
VOL −	Vol - Tv	VOL −	Vol -
CH	CH+ Tv	SHIFT + CH +	Shift + Ch +
CH	CH- Tv	SHIFT + CH −	Shift + Ch -