Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
Source	AV / Input / RDS	- V	Vol -
1	1	P-	CH- / Page-
2	2	Mute	Mute / Dimmer
3	3	[G]	Menu / Home
4	4	Up	Up
5	5	i	Info / Angle
6	6	Left	Left
7	7	OK	OK
8	8	Right	Right
9	9	Back	Back / Return
Lang	Audio / Lang I/II	Down	Down
0	0	Exit	Exit / Cancel / Clear
TXT	Text / Goto	<<	<< / Tune-
Home	Smart / List	Pause	Pause / Step / Freeze
Home	D. Menu / Top	>>	>> / Tune+
+ V	Vol +	Rec	Rec / Rec Mode

Original	Replacement	Original	Replacement
Play	Play / Slow		
Stop	Stop / Hold		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		