Mandis shop

# Denon RC-270

| Original | Replacement |
|---|---|
| Power | Power |
| Prog/Direct | Sleep |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 10 | 0 |
| +10 | Guide |
| Call | Pre Ch |
| Play | Play |
| Pause | Pause |
| Stop | Stop |

| Original | Replacement |
|---|---|
| Rec | Rec |
| >>I | >>I |
| I<< | I<< |
| >> | >> |
| << | << |
| Time | AV |
| Clear | Exit |
| Enter | Ok |
| Title | Info |
| Character | Options |
| Edit | TV/R |
| Repeat 1/ALL | Text |
| Repeat A-B | D. Menu |
| Random | Media |
| Eject | Eject |
| Memory Rec | Format |
| Synchro Rec | 3D |

https://remotecontrols.at/en/Denon/1056900-86420-replacement-remote-control-for-Denon-RC-270-00D3990473003.html