Original	Replacement	Original	Replacement
Power	Power	9	9
Sleep	Sleep / Timer	Stop/Exit/Cancel	Exit / Cancel / Clear
Mute	Mute / Dimmer	Stop/Exit/Cancel	Stop / Hold
Mode	AV / Input / RDS	-/--	Guide / EPG / -/--
1	1	0	0
2	2	Back	Back / Return
3	3	SYS Menu	Menu / Home
Eject/Nicam2	Eject / Surround	Rec	Rec / Rec Mode
Eject/Nicam2	Sound / Title	Up	Up
4	4	CH+	CH+ / Page+
5	5	DTV/Radio	TV/Radio /
6	6	Left	Left
TXT/MX	Text / Goto	Enter	OK
Play/Pause	Play / Slow	Right	Right
Play/Pause	Pause / Step / Freeze	Vol-	Vol-
7	7	Down	Down
8	8	CH-	CH- / Page-

Original	Replacement
Vol +	Vol +
Return	Shift + Back / Return
Menu DVD	D. Menu / Top
Setup	Setup / OPT /
Display	Display / Media
Search/ FAV	Shift + Red / Netflix /
Search/ FAV	Fav / Marker / PC
Slow/ EPG	Shift + Play /
Slow/ EPG	Shift + Guide / EPG / -/--
Language/ Info	Audio / Lang I/II
Language/ Info	Info / Angle
Zoom/ List	Zoom / Size
Zoom/ List	Smart / List
Red/ Angle	Red / Netflix / Search
Red/ Angle	Shift + Info / Angle
Green/ Program	Green / APP / Repeat
Green/ Program	Shift + TV/ Radio / Program

Original	Replacement
Yellow/ Repeat	Shift + Green / APP /
Yellow/ Repeat	Yellow / YouTube / Repeat
Blue/ A-B	Blue / Prime Video / Random
Blue/ A-B	Shift + Yellow / YouTube /
<</ Hold	Shift + Stop /
<</ Hold	<< / Tune-
>>/ Index	>> / Tune+
I <</ Size	I << / Preset-
I <</ Size	Shift + Zoom /
>>I / Reveal	>>I / Preset+
Subtitle	Subtitle / EQ
Title/ Subpage	Shift + Sound / Title
FAV-	Shift + Down
FAV+	Shift + Up