Mandis shop

Bel son BSA1060

Original	Replacement	Original	Replacement
Power	Power		
Play	Play		
Pause	Pause		
Stop	Stop		
Skip/Search +	>>I		
Skip/Search-	I <<		
Repeat	Text		
CD Display	Info		
Volume+	Vol +		
Volume-	Vol -		
Mute	Mute		

https://remotes.net/Belson/1060-replacement-remote-for-Belson-BSA1060.htm