Original	Replacement
On/Standby	Power
Clear/Dimmer	Exit
Memory	TV/R
Tuner	Red
CD	Green
CD Stop	Stop
CD Play / Paus	Pause
CD Play / Paus	Play
USB / Audio In	Yellow
USB Rec	Rec
USB Stop	Shift + Stop
USB Play / Pause	Shift + Pause
USB Play / Pause	Shift + Play
Play Mode	List
Tuning/Cursor Up	Up
Tuning/Cursor	Down
I<<< <<< Preset Down/Tuning/Curs or Left	Left

Original	Replacement
I<<< <<< Preset Down/Tuning/Curs	<<
I<<< <<< Preset Down/Tuning/Curs	I<<
Tuning/Cursor Right/Preset	Right
Tuning/Cursor Right/Preset	>>
Tuning/Cursor Right/Preset	>>I
Mode	Options
Enter	Ok
Display	Info
Folder	Smart
Clock/Timer	Sleep
RDS ASPM	Text
RDS PTY	Eject
RDS Display	AV
1	1
2	2
3	3
4	4

Original		Replacement	
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	GUIDE	Guide
BASS/ TREBLE	Equalizer Mode	SOUND DUAL	Dual
X-BASS / DEMO	X-Bass / Demo	AD SUBT	Subt
VOLUME -	Volume -	VOL –	Vol -
VOLUME +	Volume +	+ VOL	Vol +

Original	Replacement