Original		Replacement	
	Standby TV		Power
	Tv/Video TV	SEARCH TV/R	TV/R
	CH+ TV	+ CH	Ch +
	CH- TV	CH –	Ch -
	Vol + TV	+ VOL	Vol +
	Vol - TV	VOL –	Vol -
1	1 TV	1	1
2	2 TV	2	2
3	3 TV	3	3
4	4 TV	4	4
5	5 TV	5	5
6	6 TV	6	6
7	7 TV	7	7
8	8 TV	8	8
9	9 TV	9	9
0/10	0/10 TV	0	0
>10	-/-- TV	-/-- GUIDE	Guide

Original		Replacement	
	Enter/Memory/D.Skip TV	FAV PRE-CH	Pre Ch
	Standby AV Video	SHIFT +	Shift + Power
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	APP MEDIA	Media
SLEEP	Sleep	PROG SLEEP	Sleep
TEST TONE	Test Tone	HOME SMART	Smart
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A.F.D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
MAIN MENU	Main Menu	TOP MENU MENU	Menu
FM MODE MPX AUDIO	MPX/FM Mode/Audio Video	SHIFT + SEARCH TV/R	Shift + TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Video 1	AD SUBT	Subt

Original	Replacement
Enter/Memory/D.Skip Video 1	SHIFT + PRE-CH — Shift + Pre Ch
1 Video 1	SHIFT + 1 — Shift + 1
2 Video 1	SHIFT + 2 — Shift + 2
3 Video 1	SHIFT + 3 — Shift + 3
4 Video 1	SHIFT + 4 — Shift + 4
5 Video 1	SHIFT + 5 — Shift + 5
6 Video 1	SHIFT + 6 — Shift + 6
7 Video 1	SHIFT + 7 — Shift + 7
8 Video 1	SHIFT + 8 — Shift + 8
9 Video 1	SHIFT + 9 — Shift + 9
0/10 Video 1	SHIFT + 0 — Shift + 0
-/--/>10/Clear Video 1	SHIFT + GUIDE — Shift + Guide
AV Menu Video	TIMER AV — AV
Up Video 1	Up
Down Video 1	Down
Right Video 1	Right
Left Video 1	Left

Original	Replacement
Enter Video 1	OK — Ok
Display Video	DISPLAY INFO — Info
Master Vol +	SHIFT + VOL + — Shift + Vol +
Master Vol -	SHIFT + VOL − — Shift + Vol -
Muting	MUTE — Mute
Play Video 1	PLAY MODE — Play
Pause Video 1	Pause
Stop Video 1	Stop
<<Tuning- Video	<<
>>Tuning+	>>
I<<Preset+	I<<
>>I/Preset+ Video 1	>>I
→Advance/Step I> Video 1	SHIFT + CH + — Shift + Ch +
←/Replay/<I Step Video 1	SHIFT + CH − — Shift + Ch -

Original	Replacement
Standby System	Power
Standby AV	SHIFT + Power
Sleep	PROG SLEEP
Test Tone	HOME SMART
Play	PLAY MODE ▶
>>/ Tuning+	>>
<</ Tuning-	<<
Pause	II
Stop	■
Main Menu	TOP MENU MENU
Video 1	A
Video 2	B
SA-CD/CD	C
DVD	D
Tuner	APP MEDIA
1	1
2	2

Original	Replacement
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/ 10	0
-/--/>10/ Clear	-/-- GUIDE
Enter/ Memory/ D. S	FAV PRE-CH
Top	SHIFT + TOP MENU MENU
AV Menu	TIMER AV
Muting	MUTE
Return/ Exit	RETURN BACK
Display	DISPLAY INFO
Master Vol +	+ VOL
Master Vol -	VOL –

Original		Replacement	
PRESET –	I <</ Preset -		I <<
PRESET +	>>I / Preset +		>>I
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
ADVANCE	·→Advance/ Step I >	CH +	Ch +
REPLAY	← / Replay/ <I Step	CH –	Ch -
MUSIC	Music	SOUND DUAL	Dual
MOVIE	Movie	PICTURE FORMAT	Format
A.F.D.	A. F. D.	SETTINGS OPT	Options
DUAL MONO	Dual Mono	ECO 3D	3D
2CH	2CH	REPEAT TEXT	Text
FM MODE AUDIO	MPX/ FM	SEARCH TV/R	TV/ R
D.TUNING SUBTITLE	ANT/ D. Tuning/ Subtitle	AD SUBT	Subt
SHIFT ANGLE	Jump/ Shift/ Angle	DISC NAV LIST	List

Original	Replacement

Original		Replacement	
	Standby System		Power
	Standby AV	SHIFT +	Shift + Power
	Sleep	PROG SLEEP	Sleep
	Test Tone	HOME SMART	Smart
	Video 1	A	Red
	Video 2	B	Green
	SA-CD/CD	C	Yellow
	DVD	D	Blue
	Tuner	APP MEDIA	Media
	Main Menu	TOP MENU MENU	Menu
	Music	SOUND DUAL	Dual
	Movie	PICTURE FORMAT	Format
	2CH	REPEAT TEXT	Text
	Dual Mono	ECO 3D	3D
	A. F. D.	SETTINGS OPT	Options
	Enter/Memory/D. S	FAV PRE-CH	Pre Ch
	1	1	1

Original		Replacement	
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0/10	0	0
	-/--/>10/Clear	-/-- GUIDE	Guide
	Master Vol +	+ VOL	Vol +
	Master Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Display	DISPLAY INFO	Info
	Enter	OK	Ok
	Play	PLAY MODE ▶	Play
	Pause	⏸	Pause

Original		Replacement		Original	Replacement
	Stop		Stop		
TUNING –	<<Tuning-		<<		
TUNING +	>>Tuning+		>>		
TV CH – PRESET –	I<<Preset-		I<<		
TV CH + PRESET +	>>I / Preset+		>>I		

Original		Replacement	
VIDEO 1	Video 1	A	Red
VIDEO 2	Video 2	B	Green
SA-CD/CD	SA-CD/CD	C	Yellow
DVD	DVD	D	Blue
TUNER	Tuner	HOME SMART	Smart
SLEEP	Sleep	PROG SLEEP	Sleep
I/⏻	Standby System	⏻	Power
MAIN MENU	Main Menu	TOP MENU MENU	Menu
2CH	2CH	REPEAT TEXT	Text
A.F.D.	A.F.D.	SETTINGS OPT	Options
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
DUAL MONO	Dual Mono	ECO 3D	3D
FM MODE MPX AUDIO	MPX/FM Mode/Audio Tuner	SEARCH TV/R	TV/R
D.TUNING SUBTITLE	ANT/D.Tuning/Subtitle Tuner	AD SUBT	Subt
SHIFT ANGLE	Jump/Shift/Angle Tuner	DISC NAV LIST	List
1	1 Tuner	1	1

Original		Replacement	
2	2 Tuner	2	2
3	3 Tuner	3	3
4	4 Tuner	4	4
5	5 Tuner	5	5
6	6 Tuner	6	6
7	7 Tuner	7	7
8	8 Tuner	8	8
9	9 Tuner	9	9
0/10	0/10 Tuner	0	0
MEMORY ENTER D.SKIP	Enter/Memory/D.Skip Tuner	FAV PRE-CH	Pre Ch
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Master Vol +	+ VOL	Vol +
–	Master Vol -	VOL –	Vol -
DISPLAY	Display Tuner	DISPLAY INFO	Info
TV CH – PRESET –	I<<Preset- Tune	⏮	I<<
TV CH + PRESET +	>>I/Preset+	⏭	>>I
TUNING –	<<Tuning- Tuner	«	<<

Original	Replacement
>>/Tuning+	>>
Test Tone	Media
Standby Video	Shift + Power
MPX/FM Mode/Audio Video	Shift + TV/R
ANT/D.Tuning/Subtitle Video 2	Shift + Subt
Enter/Memory/D.Skip Video 2	Shift + Pre Ch
1 Video 2	Shift + 1
2 Video 2	Shift + 2
3 Video 2	Shift + 3
4 Video 2	Shift + 4
5 Video 2	Shift + 5
6 Video 2	Shift + 6
7 Video 2	Shift + 7
8 Video 2	Shift + 8
9 Video 2	Shift + 9
0/10 Video 2	Shift + 0
-/--/>10/Clear Video 2	Guide

Original	Replacement
AV Menu Video	AV
Up Video 2	Up
Down Video 2	Down
Right Video 2	Right
Left Video 2	Left
Enter Video 2	Ok
Display Video	Shift + Info
Play Video 2	Play
Pause Video 2	Pause
Stop Video 2	Stop
←/Replay/◁I Step Video 2	Ch -
→Advance/Step I> Video 2	Ch +
>>I/Preset+	Shift + >>I
I<<Preset- Vide	Shift + I<<
>>/Tuning+	Shift + >>
<<Tuning- Video	Shift + <<