Original		Replacement	
STANDBY	Standby		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PG+	PG +	PRESET+	>>I / Preset +
DTV/VCR	DTV / VCR	LIST SMART	Smart / List
VOL+	Vol +	VOL	Vol +
PG-	PG -	PRESET-	I << / Preset -
INFO	Info	ANGLE INFO	Info / Angle
VOL-	Vol -	VOL	Vol -
MENU	Menu	HOME MENU	Menu / Home
CH+	Up / CH +	CH PAGE	CH+ / Page+
CH+	Up / CH +		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
OK	OK	OK	OK
	Right		Right
RECORD	Record	REC MODE	Rec / Rec Mode
CH-	Down / CH -	CH PAGE	CH- / Page-

Original		Replacement	
CH-	Down / CH -		Down
TIMESHIFT	Timeshift	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
RECALL	Recall	RETURN BACK	Back / Return
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
FAV	FAV	PC FAV MARKER	Fav / Marker / PC

Original	Replacement	Original	Replacement
File	Display / Media		
TTX	Text / Goto		
Subtitle	Subtitle / EQ		
<<	<< / Tune-		
>>	>> / Tune+		
Red / Stop	Red / Netflix / Search		
Red / Stop	Stop / Hold		
Green / Step	Green / APP / Repeat		
Green / Step	Shift + Pause / Step /		
Yellow / Pause	Yellow / YouTube / Repeat		
Yellow / Pause	Pause / Step / Freeze		
Blue / Play	Blue / Prime Video / Random		
Blue / Play	Play / Slow		