Mandis shop

RC- 858

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| POWER | Power | | Power | | |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer | | |
| | Track >>I | PRESET+ | >>I / Preset+ | | |
| | Function Up | CH PAGE + | CH+ / Page+ | | |
| UP | Volume Up | VOL + | Vol + | | |
| TRACK | I<< Track | PRESET- | I<< / Preset- | | |
| FUNCTION | Function Down | CH PAGE − | CH- / Page- | | |
| DOWN VOLUME | Volume Down | VOL − | Vol - | | |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze | | |
| STOP | Stop | HOLD | Stop / Hold | | |
| PLAY | Play | SLOW | Play / Slow | | |

https://remotes.com/Denon/1560-82-replacement-remote-control-for-Denon-RC858/1395305.htm