Original	Replacement
Standby	Power
Mute	Mute
P/N	Smart
Open/Close	Eject
<<	<<
>>	>>
Play/Pause	Play
Stop	Stop
I <<	I <<
>>I	>>I
Setup	Options
Source	AV
Info	Info
Return/Exit	Exit
CH+	Ch +
CH-	Ch -
Up	Up

Original	Replacement
Down	Down
Right	Right
Left	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Slow	Back

Original	Replacement	Original	Replacement
GOTO Goto	APP MEDIA Media		
PROGRAM Program	PROG SLEEP Sleep		
TITLE/TTX Title/TTX	REPEAT TEXT Text		
AUDIO Audio	SOUND DUAL Dual		
SUBTITLE Subtitle	AD SUBT Subt		
REPEAT Red/Repeat	A Red		
A-B Green/A-B	B Green		
MENU Yellow/Menu	C Yellow		
ANGLE Blue/Angle	D Blue		
EPG EPG	-/-- GUIDE Guide		
FAVORITE Favorite	FAV PRE-CH Pre Ch		
TV/RADIO Tv/Radio	SEARCH TV/R TV/R		
ZOOM Zoom	SHIFT + ZOOM Shift + Eject		