Original		Replacement	
TV DIRECT	TV Direct	LIST SMART	Smart / List
DVD	Power DVD	NETFLIX SEARCH	Red / Netflix / Search
VCR	Power VCR	APP REPEAT	Green / APP / Repeat
AUDIO	Power Audio		Power
STB	Power STB	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TV	Power TV	Prime Video RANDOM	Blue / Prime Video / Random
DVD	DVD	DVD 2	2
VCR	VCR	VIDEO 4	4
TV	TV	TV 1	1
FM/AM	FM/AM	TUNER 6	6
TV/VIDEO	Tv/Video	TAPE 5	5
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CHANNEL +	Channel +	CH PAGE +	CH+ / Page+
VOLUME +	Volume+	VOL +	Vol +
—	Channel -	CH PAGE −	CH- / Page-
—	Volume-	VOL −	Vol -
ON SCREEN DISPLAY	Display/On Screen	MEDIA DISPLAY	Display / Media

Original		Replacement	
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ANALOG/DIGITAL INPUT	Analog/Digital Input	RDS AV INPUT	AV / Input / RDS
SMART S SETUP	Smart S Setup	OPT-TOOLS SETUP	Setup / OPT /
BASS BOOST	Bass Boost	LANG I/II AUDIO	Audio / Lang I/II
TONE	C. Tone	EQ SUBTITLE	Subtitle / EQ
A.POSITION	A. Position	TOP MENU D.MENU	D.Menu / Top
TEST	Test Tone	GOTO TEXT	Text / Goto
EFFECT	Effect	ANGLE INFO	Info / Angle
DECODE	Decode	PROGRAM TV/RADIO	TV/Radio /
SURROUND	Surround	SURROUND ⏏	Eject / Surround
SUBWFR +	Subwfr+	▶	Right
CENTER +	Center+	▲	Up
L-SUR +	Surr L+	SHIFT + VOL +	Shift + Vol +
SURR-R +	Surr R+	SHIFT + CH PAGE +	Shift + CH+ /
−	Subwfr-	◀	Left
−	Center-	▼	Down

Original	Replacement	Original	Replacement
Surr L-	SHIFT + VOL – Shift + Vol -		
Surr R-	SHIFT + CH PAGE – Shift + CH- /		

Original	Replacement
Power Audio	Power
Power Tv	SHIFT + Power
FM/AM	Eject / Surround
Tv Vol +	Vol +
Channel + TV	CH+ / Page+
Tv Vol -	Vol -
Channel - TV	CH- / Page-
Tuning- FM/AM	<< / Tune-
FM Mode FM/AM	Smart / List
Tuning+ FM/AM	>> / Tune+
Memory FM/AM	Menu / Home
TA/News/Info	Info / Angle
TA/News/Info	Up
PTY- FM/AM	Left
PTY+ FM/AM	Right
PTY Search	Down
PTY Search	Red / Netflix / Search

Original	Replacement
Display FM/AM	Display / Media
1 FM/AM	SHIFT + 1
1 TV	1
2 FM/AM	SHIFT + 2
2 TV	2
3 FM/AM	SHIFT + 3
3 TV	3
4 FM/AM	SHIFT + 4
4 TV	4
5 FM/AM	SHIFT + 5
5 TV	5
6 FM/AM	SHIFT + 6
6 TV	6
7 FM/AM	SHIFT + 7
7 TV	7
8 FM/AM	SHIFT + 8
8 TV	8

Original		Replacement		Original	Replacement
9	9 FM/AM	SHIFT + BLUETOOTH 9	Shift + 9		
9	9 TV	BLUETOOTH 9	9		
TV RETURN 10	10 FM/AM	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC		
TV RETURN 10	10/Tv Return TV	SHIFT + HDMI - SAT 0	Shift + 0		
0	0 TV	HDMI - SAT 0	0		
100+ +10	+10/100+	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		
100+ +10	+10 TV	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement	
	Power DVD		Power
	I <<	PRESET-	I << / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Top Menu	TOP MENU D.MENU	D. Menu / Top
	>>	TUNE+	>> / Tune+
	Up		Up
	Menu	HOME MENU	Menu / Home
	Left	SHIFT +	Shift + Left
	Enter	OK	OK
	Right		Right
	Set Up	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
	On Screen	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Original		Replacement	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Title Group	SHIFT + TITLE SOUND	Shift + Sound / Title
	Return	RETURN BACK	Back / Return
	DVD Zoom	SIZE ZOOM	Zoom / Size
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	VFP Progressive	LIST SMART	Smart / List
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	←		Left
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	Angle	ANGLE INFO	Info / Angle

Original		Replacement		Original	Replacement
TV RETURN 10	10	GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC		
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media		
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title		
SURROUND	Surround	SURROUND	Eject / Surround		

Original	Replacement
Power VCR	SHIFT + Power (Shift + Power)
Power STB	Power
VCR	SHIFT + GUIDE EPG (Shift + Guide / EPG / -/--)
Muting	DIMMER MUTE (Mute / Dimmer)
Channel +	CH PAGE + (CH+ / Page+)
Volume+	VOL + (Vol +)
Channel -	CH PAGE − (CH- / Page-)
Volume-	VOL − (Vol -)
Play VCR	SLOW ▶ (Play / Slow)
<< VCR	TUNE- ◀◀ (<< / Tune-)
Stop/Memory	HOLD ■ (Stop / Hold)
Pause VCR	STEP-FREEZE ❚❚ (Pause / Step / Freeze)
>> VCR	TUNE+ ▶▶ (>> / Tune+)
1 VCR	SHIFT + TV 1 (Shift + 1)
1 STB	TV 1 (1)
2 VCR	SHIFT + DVD 2 (Shift + 2)
2 STB	DVD 2 (2)

Original	Replacement
3 VCR	SHIFT + CD-STB 3 (Shift + 3)
3 STB	CD-STB 3 (3)
4 VCR	SHIFT + VIDEO 4 (Shift + 4)
4 STB	VIDEO 4 (4)
5 VCR	SHIFT + TAPE 5 (Shift + 5)
5 STB	TAPE 5 (5)
6 VCR	SHIFT + TUNER 6 (Shift + 6)
6 STB	TUNER 6 (6)
7 VCR	SHIFT + AUX-HDD 7 (Shift + 7)
7 STB	AUX-HDD 7 (7)
8 VCR	SHIFT + USB 8 (Shift + 8)
8 STB	USB 8 (8)
9 VCR	SHIFT + BLUETOOTH 9 (Shift + 9)
9 STB	BLUETOOTH 9 (9)
+10 TV	-/-- GUIDE EPG (Guide / EPG / -/--)
0 VCR	SHIFT + HDMI-SAT 0 (Shift + 0)
0 STB	HDMI-SAT 0 (0)