Original		Replacement	
	Power		Power
	Input TV		AV / Input / RDS
	Input Av		Shift + AV / Input / RDS
	Aspect		Picture / Format
	Viera Link		Smart / List
	Option		Setup / OPT /
	Direct TV Rec		Rec / Rec Mode
	Guide		Guide / EPG / -/--
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home
	Down		Down
	Return		Back / Return
	Red		Red / Netflix / Search

Original		Replacement	
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto
	STTL		Subtitle / EQ
	Index		TV/Radio /
	Hold		Shift + Stop /
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
i	i		Info / Angle

Original	Replacement
0 / VCR	0
0 / VCR	Shift + 4
Mute	Mute / Dimmer
CH+	CH+ / Page+
Vol +	Vol +
CH-	CH- / Page-
Vol -	Vol -
DVD Power	Shift + Power
DVD Rec	Shift + Rec / Rec Mode
DVD	Shift + CH- /
DVD	Shift + CH+ /
DVD << / I <<	I << / Preset-
DVD << / I <<	<< / Tune-
DVD >> / >>I	>> / Tune+
DVD >> / >>I	>>I / Preset+
DVD Stop	Stop / Hold
DVD Pause / Step	Pause / Step / Freeze

Original	Replacement
DVD Play	Play / Slow

Original	Replacement	Original	Replacement
Power DVD	Power		
Rec DVD	Rec / Rec Mode		
Programme Down	CH- / Page-		
Programme Up	CH+ / Page+		
I << DVD	I << / Preset-		
<< DVD	<< / Tune-		
>>I DVD	>>I / Preset+		
>> DVD	>> / Tune+		
Stop DVD	Stop / Hold		
Pause/Step DVD	Pause / Step / Freeze		
Play DVD	Play / Slow		

Original	Replacement
VCR Power	Power
VCR Rec	Rec / Rec Mode
VCR	CH- / Page-
VCR	CH+ / Page+
VCR << / I <<	<< / Tune-
VCR << / I <<	I << / Preset-
VCR >> / >>I	>>I / Preset+
VCR >> / >>I	>> / Tune+
VCR Stop	Stop / Hold
VCR Pause / Step	Pause / Step / Freeze
VCR Play	Play / Slow

Original	Replacement