Original	Replacement	Original	Replacement
Power	Power	Enter	Ok
Display	Info	Right	Right
DVD / BD	Shift + 1	Down	Down
VCR / DVR	Shift + 2	Setup	Options
CBL/SAT	Shift + 3	Return	Back
CD	Shift + 4	Audio	Dual
AUX	Shift + 5	I <<	I <<
TV / TAPE	Shift + 6	>>I	>>I
TUNER	Shift + 7	<<	<<
PORT	Shift + 8	Play	Play
Muting	Mute	>>	>>
CH/Disc/Album	Ch +	Pause	Pause
CH/Disc/Album	Ch -	Stop	Stop
Vol +	Vol +	Movie	Red
Vol -	Vol -	Music/Repeat	Green
Up	Up	Game/Random	Yellow
Left	Left	Stereo/Play Mode	Blue

Original		Replacement		Original	Replacement
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0 11	0/ 11	0	0		
+10 D.TUN DIMMER	+10/ - - / - - - 10/ Dimmer / D. Tun	GUIDE	Guide		
CLR SLEEP 12	CLR/ Sleep/ 12	FAV PRE-CH	Pre Ch		

Original	Replacement
Power BD/DVD	Power
Menu/Prev CH	Menu
Top Menu/Guide BD/DVD	Options
Setup BD/DVD	Smart
Return BD/DVD	Back
Audio BD/DVD	Media
Enter BD/DVD	Ok
Up BD/DVD	Up
Down BD/DVD	Down
Right BD/DVD	Right
Left BD/DVD	Left
I << BD/DVD	I <<
>>I BD/DVD	>>I
<< BD/DVD	<<
>> BD/DVD	>>
Play BD/DVD	Play
Pause/Play rev. BD/DVD	Pause

Original	Replacement
Stop BD/DVD	Stop
Movie Tv/Search BD/DVD	Red
Music/Repeat	Green
Game/Random	Yellow
Stereo/Play Mode BD/DVD	Blue
1 BD/DVD	1
2 BD/DVD	2
3 BD/DVD	3
4 BD/DVD	4
5 BD/DVD	5
6 BD/DVD	6
7 BD/DVD	7
8 BD/DVD	8
9 BD/DVD	9
0/11 BD/DVD	0
+10/--/--10/D.Tu Dimmer BD/DVD	Guide
CLR/Sleep/12	Pre Ch

BD/DVD

Original	Replacement
CBL/SAT	Text
Muting Receiver	Mute
Vol + Receiver	Vol +
Vol - Receiver	Vol -
Power CBL/SAT	Shift + Power
CH Disc/Album+ CBL/SAT	Ch +
CH Disc/Album- CBL/SAT	Ch -
Menu/Prev CH CBL/SAT	Shift + Menu
Top Menu/Guide CBL/SAT	Shift + Options
Return CBL/SAT	Shift + Back
Setup CBL/SAT	Shift + Smart
Up CBL/SAT	Shift + Up
Enter CBL/SAT	Shift + Ok
Down CBL/SAT	Shift + Down
Right CBL/SAT	Shift + Right
Left CBL/SAT	Shift + Left
Pause/Play rev. CBL/SAT	Shift + Pause

Original	Replacement
Stop CBL/SAT	Shift + Stop
<< CBL/SAT	Shift + Ch -
>> CBL/SAT	Shift + Ch +
Play CBL/SAT	3D
Movie Tv/Search CBL/SAT	Dual
Music/Repeat CBL/SAT	Subt
Game/Random	AV
Stereo/Play Mode CBL/SAT	Format
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8
9 CBL/SAT	Shift + 9

Original	Replacement	Original	Replacement
0/ 11 CBL/ SAT	SHIFT + 0 Shift + 0		
DVD/ BD	SEARCH TV/R TV/ R		

Original	Replacement	Original	Replacement
Power CD	Power	Stop CD	Stop
CH/Disc+ CD	Ch +	Movie Tv/Search	Red
CH/Disc- CD	Ch -	Music/Repeat	Green
Return CD	Back	Game/Random	Yellow
Setup CD	Smart	Stereo/Play Mode	Blue
Audio CD	Media	1 CD	1
Up CD	Up	2 CD	2
Down CD	Down	3 CD	3
Right CD	Right	4 CD	4
Left CD	Left	5 CD	5
Enter CD	Ok	6 CD	6
I << CD	I <<	7 CD	7
>>I CD	>>I	8 CD	8
<< CD	<<	9 CD	9
>> CD	>>	0/11 CD	0
Play CD	Play	+10/--/--10/D.Tu Dimmer CD	Guide
Pause CD	Pause	CLR/Sleep/12	Pre Ch

CD

Original	Replacement	Original	Replacement
MUTING Muting Receiver	MUTE Mute		
VOL Vol + Receiver	+ VOL Vol +		
VOL Vol - Receiver	VOL − Vol -		
CD CD	SEARCH TV/R TV/R		

Original	Replacement	Original	Replacement
Power Receiver Zone 2	Power	>> Zone 2	>>
Muting Receiver	Mute	<< Zone 2	<<
Vol + Zone 2	Vol +	Pause Zone 2	Pause
Vol - Zone 2	Vol -	Stop Zone 2	Stop
CH Disc/Album+ Zone 2	Ch +	Movie Tv/Search Zone 2	Red
CH Disc/Album- Zone 2	Ch -	Music/Repeat	Green
Up Zone 2	Up	Game/Random	Yellow
Enter Zone 2	Ok	Stereo/Play Mode Zone 2	Blue
Down Zone 2	Down	1 Zone 2	1
Right Zone 2	Right	2 Zone 2	2
Left Zone 2	Left	3 Zone 2	3
Return Zone 2	Back	4 Zone 2	4
Setup Zone 2	Smart	5 Zone 2	5
Audio Zone 2	Media	6 Zone 2	6
I << Zone 2	I <<	7 Zone 2	7
>>I Zone 2	>>I	8 Zone 2	8
Play Zone 2	Play	9 Zone 2	9

Original	Replacement	Original	Replacement
0/ 11 Zone 2	0		
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		