Mandis shop

R- 40A01

Original	Replacement	Original	Replacement
Power	Power	Menu	Menu / Home
1	1	Right/[≡o]	Right
2	2	Vol +	Vol +
3	3	Down	Down
4	4	PR-	CH- / Page-
5	5	Sleep/[≡♦]	Sleep / Timer
6	6	Mute	Mute / Dimmer
7	7	Recall/[≡?]	Back / Return
8	8	Red/Skip	Red / Netflix / Search
9	9	Green/Movie	Green / APP / Repeat
Source/[≡]	AV / Input / RDS	[≡x]	Exit / Cancel / Clear
0	0	Yellow/Delete	Yellow / YouTube / Repeat
NORMALIOK	OK	Blue/Mode	Blue / Prime Video / Random
PR+	CH+ / Page+	[≡]	Text / Goto
Up	Up		
Vol -	Vol -		
Left/[≡+]	Left		

https://remotes.at/e/1603-239-replacement-remote-control-for-R-40A15-4B574B0B1.htm