Mandis shop

R- 40A01

Original	Replacement	Original	Replacement
Power	Power	Menu	Menu / Home
1	1	Right / [≡o]	Right
2	2	Vol +	Vol +
3	3	Down	Down
4	4	PR-	CH- / Page-
5	5	Sleep / [≡♦]	Sleep / Timer
6	6	Mute	Mute / Dimmer
7	7	Recall / [≡?]	Back / Return
8	8	Red / Skip	Red / Netflix / Search
9	9	Green / Movie	Green / APP / Repeat
Source / [≡]	AV / Input / RDS	[≡x]	Exit / Cancel / Clear
0	0	Yellow / Delete	Yellow / YouTube / Repeat
Normal / OK / [≡i]	OK	Blue / Mode	Blue / Prime Video / Random
PR+	CH+ / Page+	[≡]	Text / Goto
Up	Up		
Vol -	Vol -		
Left / [≡+]	Left		

https://remotecontrols.at/en/16103-2379-replacement-remote-control-for-R-40A15-4357-9801.html