Original		Replacement	
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/BAND	Tuner/Band	B	Green
TAPE	Tape	A	Red
VCR	VCR	HOME SMART	Smart
VOL +	Vol +	+ VOL	Vol +
– VO	Vol -	VOL –	Vol -
MUTING	Muting	MUTE	Mute
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
SELECT	Select	OK	Ok
MENU	Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
DISC/DECK 1/2	Disc/Deck 1/2	TOP MENU MENU	Menu

Original		Replacement	
TV/AV	Tv/AV	TIMER AV	AV
PRO LOGIC	Pro Logic	APP MEDIA	Media
– CENT	Center -	SHIFT + CH –	Shift + Ch -
NTER +	Center +	SHIFT + + CH	Shift + Ch +
TEST	Test	RETURN BACK	Back
ROUND +	Surround +	+ CH	Ch +
– SURRO	Surround -	CH –	Ch -
POWER	Power TV	⏻	Power
VOL +	Tv Vol Up	SHIFT + + VOL	Shift + Vol +
– TV V	Tv Vol Down	SHIFT + VOL –	Shift + Vol -
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7

Original		Replacement		Original		Replacement	
8	8 Tv	8	8				
9	9 Tv	9	9				
0	0 Tv	0	0				
≥10/-/--	>10/ - / - - Tv	-/-- GUIDE	Gui de				

Original		Replacement	
POWER	Power DVD		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
TUNER/ BAND	Tuner/Band	B	Green
TAPE	Tape	A	Red
CD	CD	C	Yellow
DVD	DVD	D	Blue
	Play DVD	PLAY MODE	Play
	I<</<< DVD		<<
	Stop DVD		Stop
	>>/>>I DVD		>>
DISC/DECK 1/2	Disc/Deck 1/2	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	E-MANUAL D.MENU	D. Menu
	Up		Up
	Down		Down
	Right		Right

Original		Replacement	
	Left		Left
SELECT	Select	OK	Ok
TEST	Test	RETURN BACK	Back
PRO LOGIC	Pro Logic	APP MEDIA	Media
– CENTER	Center-	SHIFT + CH –	Shift + Ch -
CENTER +	Center+	SHIFT + CH +	Shift + Ch +
SURROUND +	Surround +	+ CH	Ch +
– SURROUND	Surround -	– CH	Ch -
1	1 DVD	1	1
2	2 DVD	2	2
3	3 DVD	3	3
4	4 DVD	4	4
5	5 DVD	5	5
6	6 DVD	6	6
7	7 DVD	7	7
8	8 DVD	8	8
9	9 DVD	9	9

Original		Replacement	
0	0 DVD	0	0
≥10/-/--	>10/ - / - - DVD	-/-- GUIDE	Gui de
VOL +	Vol +	+ VOL	Vol +
– VO	Vol -	VOL –	Vol -
MUTING	Mut i ng	MUTE	Mut e

Original	Replacement

Original		Replacement	
POWER	Power CD		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
CD	CD	C	Yellow
DVD	DVD	D	Blue
TAPE	Tape	A	Red
TUNER/ BAND	Tuner/Band	B	Green
	Stop CD		Stop
	I<</<< CD	<<	<<
	>>/>>I CD	>>	>>
	Play CD	PLAY MODE	Play
MENU	Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
DISC/DECK 1/2	Disc/Deck 1/2	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right

Original		Replacement	
	Left		Left
SELECT	Select	OK	Ok
TEST	Test	RETURN BACK	Back
PRO LOGIC	Pro Logic	APP MEDIA	Media
CENTER -	Center-	SHIFT + CH -	Shift + Ch -
CENTER +	Center+	SHIFT + CH +	Shift + Ch +
SURROUND +	Surround +	CH +	Ch +
SURROUND -	Surround -	CH -	Ch -
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute
POWER	Power Tape	SHIFT +	Shift + Power
	Stop Tape	SHIFT +	Shift + Stop
	Play Tape	SHIFT + PLAY MODE	Shift + Play
	I<</<< Tape	SHIFT +	Shift + <<
	>>/>>I Tape	SHIFT +	Shift + >>
DISC/DECK 1/2	Disc/Deck 1/2	SHIFT + TOP MENU MENU	Shift + Menu

Tape

Original		Replacement		Original	Replacement
1	1 CD- Tape	1	1		
2	2 CD- Tape	2	2		
3	3 CD- Tape	3	3		
4	4 CD- Tape	4	4		
5	5 CD- Tape	5	5		
6	6 CD- Tape	6	6		
7	7 CD- Tape	7	7		
8	8 CD- Tape	8	8		
9	9 CD- Tape	9	9		
0	0 CD- Tape	0	0		
≥10/-/--	>10/-/-- CD- Tape	-/-- GUIDE	Guide		
DIRECT TUNING/ DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text		

Original		Replacement	
POWER	Power VCR		Power
VCR	VCR	HOME SMART	Smart
TAPE	Tape	A	Red
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
	Stop		Stop
I<</<<		<<	
>>/>>I		>>	
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5
6	6 VCR	6	6

Original		Replacement	
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/-/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING/ DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
SELECT	Select	OK	Ok
DISC/DECK 1/2	Disc/Deck 1/2	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	E-MANUAL D.MENU	D. Menu

Original		Replacement	
TEST	Test	RETURN BACK	Back
PRO LOGIC	Pro Logic	APP MEDIA	Media
CENTER -	Center -	SHIFT + CH -	Shift + Ch -
CENTER +	Center +	SHIFT + CH +	Shift + Ch +
SURROUND +	Surround +	CH +	Ch +
SURROUND -	Surround -	CH -	Ch -
POWER	Power Tuner/Band	SHIFT + ⏻	Shift + Power
1	1 Tuner/Band	SHIFT + 1	Shift + 1
2	2 Tuner/Band	SHIFT + 2	Shift + 2
3	3 Tuner/Band	SHIFT + 3	Shift + 3
4	4 Tuner/Band	SHIFT + 4	Shift + 4
5	5 Tuner/Band	SHIFT + 5	Shift + 5
6	6 Tuner/Band	SHIFT + 6	Shift + 6
7	7 Tuner/Band	SHIFT + 7	Shift + 7
8	8 Tuner/Band	SHIFT + 8	Shift + 8
9	9 Tuner/Band	SHIFT + 9	Shift + 9
0	0 Tuner/Band	SHIFT + 0	Shift + 0

Original		Replacement	
≥10/-/--	>10/-/--	SHIFT + -/-- GUIDE	Shift + Guide