Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
LIST	List	DISC NAV LIST	List
INFO	Info	DISPLAY INFO	Info
	Google Assistant	E-MANUAL D.MENU	D. Menu
HOME	Home	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu

Original		Replacement	
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
NETFLIX	NETFLIX	APP MEDIA	Media
prime video	prime video	SHIFT + APP MEDIA	Shift + Media
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
GUIDE	Guide	-/-- GUIDE	Guide
SOURCE	Source	TIMER AV	AV
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
REVEAL	<< / Reveal	<<	<<
INDEX	Play / Index	PLAY MODE	Play

Original		Replacement		Original	Replacement
HOLD	>> / Hold		>>		
SUBTITLE	Subtitle	AD SUBT	Subt		
II	Pause	II	Pause		
■	Stop	■	Stop		
R	Red	A	Red		
G	Green	B	Green		
Y	Yellow	C	Yellow		
B	Blue	D	Blue		
TEXT	Text	REPEAT TEXT	Text		
FAV	Fav	FAV PRE-CH	Pre Ch		
AD	AD	SHIFT + AD SUBT	Shift + Subt		
I/II	I/II	SOUND DUAL	Dual		