Original		Replacement	
	Power TV- SAT		Power
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
	Menu	TOP MENU MENU	Menu
	Guide	GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
0	0	0	0
VOLUME +	Volume+ Tv	VOL +	Vol +
VOLUME –	Volume- Tv	VOL –	Vol -
CHANNEL +	CH+ Tv Control	CH +	Ch +
CHANNEL –	CH- Tv Control	CH –	Ch -
TV/SAT	TV/SAT	APP MEDIA	Media
FRONT	Front	HOME SMART	Smart
SOURCE	Power Front	SHIFT +	Shift + Power
	Play Front	PLAY MODE	Play
	>> Front		>>
EXIT	<< Front		<<
CLASS C	Pause Front		Pause
MPX D	Stop Front		Stop
ENTER	Enter Down	ECO 3D	3D
INPUT SELECT	Input Select	TIMER AV	AV
1	1 Front	SHIFT + 1	Shift + 1

Original	Replacement	Original	Replacement
2 Front	SHIFT + 2 Shift + 2		
3 Front	SHIFT + 3 Shift + 3		
4 Front	SHIFT + 4 Shift + 4		
5 Front	SHIFT + 5 Shift + 5		
6 Front	SHIFT + 6 Shift + 6		
7 Front	SHIFT + 7 Shift + 7		
8 Front	SHIFT + 8 Shift + 8		
9 Front	SHIFT + 9 Shift + 9		
0 Front	SHIFT + 0 Shift + 0		
Channel + Front	SHIFT + CH + Shift + Ch +		
Channel - Front	SHIFT + CH – Shift + Ch -		

Original		Replacement	
SOURCE	Power DVD		Power
MASTER VOLUME +	Master	VOL +	Vol +
MASTER VOLUME –	Master Volume-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
T.EDIT MENU	Menu	TOP MENU MENU	Menu
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
SUBTITLE RF ATT GUIDE	Subtitle	AD SUBT	Subt
AUDIO EON	Audio	SOUND DUAL	Dual
TUNE +	Up		Up
TUNE –	Down		Down
ST+	Right		Right
ST–	Left		Left
ENTER	Enter	OK	Ok
	Play	PLAY MODE	Play
EXIT	<<		<<
	>>		>>
SEARCH B	I<<		I<<

Original		Replacement	
CLASS C	Pause		Pause
MPX D	Stop		Stop
D.ACCESS E	>>I		>>I
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	·/+10	FAV PRE-CH	Pre Ch

Original		Replacement	
SOURCE	Power FM-AM		Power
MASTER VOLUME +	Master	VOL +	Vol +
MASTER VOLUME -	Master Volume-	VOL -	Vol -
MUTE	Mute	MUTE	Mute
TOP MENU P+	Display	DISPLAY INFO	Info
T.EDIT MENU	T. Edit	HOME SMART	Smart
SUBTITLE RF ATT GUIDE	RF ATT	APP MEDIA	Media
AUDIO EON P- EXIT	EON	DISC NAV LIST	List
TUNE +	Tune+		Up
TUNE -	Tune-		Down
ST+	ST+		Right
ST-	ST-		Left
ENTER	Enter	OK	Ok
D.ACCESS E	D. Access	D	Blue
MPX D	MPX	C	Yellow
CLASS C	Class	B	Green
SEARCH B	Search	SEARCH TV/R	TV/R

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
RECEIV	Power Receiver		Power
SIGNAL SELECT	Signal Select	HOME SMART	Smart
SOURCE	Power DVR-VCR	SHIFT +	Shift + Power
DVD	DVD	SHIFT + 1	Shift + 1
TV/SAT	TV/SAT	SHIFT + 5	Shift + 5
FRONT	Front	SHIFT + 4	Shift + 4
SLEEP	Sleep	PROG SLEEP	Sleep
DVR/VCR	DVR/VCR	SHIFT + 2	Shift + 2
FM/AM	FM/AM	SHIFT + 3	Shift + 3
DIMMER	Dimmer	APP MEDIA	Media
AUTO	Auto	E-MANUAL D.MENU	D. Menu
SURROUND	Surround	SOUND DUAL	Dual
ADVANCED	Advanced	AD SUBT	Subt
SOUND MODE	Sound Mode	PICTURE FORMAT	Format
SETUP	Setup	SETTINGS OPT	Options
TEST TONE	Test Tone	REPEAT TEXT	Text
CH.SELECT	CH. Select	ECO 3D	3D

Original		Replacement	
ROOM SETUP	Room Setup	A	Red
MUTE	Mute	MUTE	Mute
–	-	B	Green
+	+	C	Yellow
ENTER	Enter (Up)	SHIFT + FAV PRE-CH	Shift + Pre Ch
MASTER VOLUME –	Master Volume-	VOL –	Vol -
MASTER VOLUME +	Master	+ VOL	Vol +
TOP MENU P+	P+	+ CH	Ch +
TUNE +	Up/Tune+		Up
T.EDIT MENU	Menu	TOP MENU MENU	Menu
ST–	Left/ST-		Left
ENTER	Enter	OK	Ok
ST+	Right/ST+		Right
AUDIO EON P– EXIT	P-	CH –	Ch -
TUNE –	Down/Tune-		Down
SUBTITLE RF ATT GUIDE	Guide	-/-- GUIDE	Guide
EXIT	<<		<<

Original		Replacement	
▶	Play	PLAY MODE ▶	Play
▶▶	>>/ A	≫	>>
SEARCH B ⏮	I <</ B	⏮	I <<
CLASS C ⏸	Pause/ C	⏸	Pause
MPX D ■	Stop/ D	■	Stop
D.ACCESS E ⏭	>>I / E	⏭	>>I
1	1	1	1
2	2	2	2
3	3	3	3
ENTER	Enter Down	TIMER AV	AV
4	4	4	4
5	5	5	5
6	6	6	6
+10 ·	· / +10	FAV PRE-CH	Pre Ch
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
+ CHANNEL	Channel +	SHIFT + CH +	Shift + Ch +
CHANNEL –	Channel -	SHIFT + CH –	Shift + Ch -