Original		Replacement	
ON/STAND-BY	On/Standby		Power
OPEN / CLOSE	Open/Close	ZOOM	Eject
TUNER(BAND)	Tuner (Band)	B	Green
ASPM	ASPM	HOME SMART	Smart
PTY	RDS-PTY	APP MEDIA	Media
DISPLAY	Display	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
X-BASS	X-Bass	SETTINGS OPT	Options
BASS / TREBLE	Bass/Treble	AD SUBT	Subt
MEMORY	Memory	ECO 3D	3D
CLEAR	Clear	CLEAR EXIT	Exit
CLOCK / TIMER	Clock/Timer	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
FOLDER	Folder	PICTURE FORMAT	Format
PLAY MODE	Play Mode	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2

Original		Replacement	
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+	10+	-/-- GUIDE	Guide
iPod/iPhone DISPLAY (TV OUT)	(Tv Out)/Display iPod/iPhone	SEARCH TV/R	TV/R
MENU	Menu iPod/iPhone	TOP MENU MENU	Menu
▶/II	Play/Pause iPod/iPhone	II	Pause
CD/USB DISPLAY	Display CD/USB	RETURN BACK	Back
■	Stop CD/USB	■	Stop
▶/II	Play/Pause	PLAY MODE ▶	Play
TUNING	<< Tuning	<<	<<
TUNING	I <<	I <<	I <<

Original		Replacement	
	>>I		>>I
	Tuning >>		>>
	Preset Up		Up
	Preset Down		Down
	Vol +		Vol +
	Vol -		Vol -
	Enter		Ok
	Equalizer Mode		Dual
	Demo/Dimmer		Text
	iPod/iPhone		Red
	CD		Yellow
	USB		Blue
	Audio In		Pre Ch

Original	Replacement