Mandis shop

LG COV34445442

Original		Replacement	
	Power		Power
F	F	TOP MENU MENU	Menu
VOL +	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
ASC	ASC	HOME SMART	Smart
	Mute	MUTE	Mute
STANDARD	Standard	SOUND DUAL	Dual
CINEMA	Cinema	SEARCH TV/R	TV/R
▶/II	Play	PLAY MODE ▶	Play
▶/II	Pause	II	Pause
▶▶I	>>I	≫	>>I
I◀◀	I <<	≪	I <<
DRC ON	DRC On	A	Red
DRC OFF	DRC Off	B	Green
WOOFER LEVEL +	Woofer Level +	+ CH	Ch +
WOOFER LEVEL −	Woofer Level -	CH −	Ch -
AUTO POWER ON	Auto Power On	C	Yellow

Original		Replacement	
AUTO POWER OFF	Auto Power Off	D	Blue

https://remotes.at/en/LG/10336-836-replacement-remote-control-for-LG-COV34445442.htm