Original		Replacement	
STANDBY	Standby		Power
P/N	P/N	TIMER SLEEP	Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
EJECT	Eject	SURROUND	Eject / Surround
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ANGLE	Angle	ANGLE INFO	Info / Angle

Original		Replacement	
0	0	HDMI-SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
PBC	PBC	FORMAT PICTURE	Picture / Format
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
RETURN	Return	RETURN BACK	Back / Return
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
TITLE	Title	TITLE SOUND	Sound / Title
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
CHANNEL	Channel	LIST SMART	Smart / List
RESET	Reset	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Replacement		Original		Replacement	
MARK	Mark	PC FAV MARKER	Fav / Marker / PC	NEXT	>>I	PRESET+	>>I / Preset+
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
SLOW	I>/ Slow	SHIFT + SLOW	Shift + Play /				
A-B	↔/ A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
PSCAN	P. Scan	GOTO TEXT	Text / Goto				
MODE	Mode	TOP MENU D.MENU	D. Menu / Top				
DISPLAY	Display	MEDIA DISPLAY	Display / Media				
3D	3D	SHIFT + CD-STB 3	Shift + 3				
VOL -	Vol -	VOL −	Vol -				
VOL +	Vol +	+ VOL	Vol +				
STOP	Stop	HOLD	Stop / Hold				
STEP	Step	SHIFT + STEP-FREEZE	Shift + Pause / Step /				
PLAY/PAUSE	Play	SLOW	Play / Slow				
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
F.REV	<<	TUNE-	<< / Tune-				
F.FWD	>>	TUNE+	>> / Tune+				
PREV	I <<	PRESET-	I << / Preset-				