Original		Replacement	
	Power		Power
	Energy Saving	SHIFT +	ECO 3D Shift + 3D
	AV Mode	SHIFT +	TIMER AV Shift + AV
	Input		TIMER AV AV
	Tv/Radio		SEARCH TV/R TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
LIST	List		DISC NAV LIST List
Q.VIEW	Q.View		APP MEDIA Media

Original		Replacement	
	Vol +		VOL Vol +
	Vol -		VOL Vol -
	FAV		FAV PRE-CH Pre Ch
	3D		ECO 3D 3D
	Mute		MUTE Mute
	P+		CH Ch +
	P-		CH Ch -
GUIDE	Guide		GUIDE Guide
Home	Home		HOME SMART Smart
Q.MENU	Q Menu		TOP MENU MENU Menu
	Up		Up
	Left		Left
	OK		OK Ok
	Right		Right
	Down		Down
BACK	Back		RETURN BACK Back
INFO	Info		DISPLAY INFO Info

Original		Replacement	
EXIT	Exit	CLEAR EXIT	Exit
	Red	A	Red
	green	B	Green
	Yellow	C	Yellow
3D SETTING	Blue	D	Blue
TEXT	Text	REPEAT TEXT	Text
T.OPT	T. OPT	SETTINGS OPT	Options
SUBTITLE	Subtitle	AD SUBT	Subt
■	Stop	■	Stop
▶	Play	PLAY MODE ▶	Play
II	Pause	II	Pause
<<	<<	<<	<<
>>	>>	>>	>>
SIMPLINK	Simplink	E-MANUAL D.MENU	D. Menu
RATIO	Ratio	PICTURE FORMAT	Format
AD	AD	SHIFT + AD SUBT	Shift + Subt

Original	Replacement