| Original | | Replacement | |
|---|---|---|---|
| AUDIO | Audio Standby/On | | Power |
| 1 | 1 / Center- | 1 | 1 |
| 2 | 2 / Center+ | 2 | 2 |
| 3 | 3 / Subwoofer- | 3 | 3 |
| 4 | 4 / Subwoofer+ | 4 | 4 |
| 5 | 5 / Rear-L- | 5 | 5 |
| 6 | 6 / Rear-L+ | 6 | 6 |
| 7 | 7 / Rear-R- | 7 | 7 |
| 8 | 8 / Rear-R+ | 8 | 8 |
| 9 | 9 / Test | 9 | 9 |
| CLEAR | Clear | CLEAR EXIT | Exit |
| 0 | 0 / Setting | 0 | 0 |
| 0 | 0 / Setting | SETTINGS OPT | Options |
| SOUND | Sound | SOUND DUAL | Dual |
| DVD | DVD | HOME SMART | Smart |
| FM MODE | FM mode | SEARCH TV/R | TV/R |
| FM/AM | FM/AM | APP MEDIA | Media |

| Original | | Replacement | |
|---|---|---|---|
| AUX | AUX | TIMER AV | AV |
| RDS | RDS | + CH | Ch + |
| SEARCH | Search | SHIFT + SEARCH TV/R | Shift + TV/R |
| MUTING | Muting | MUTE | Mute |
| REC/MEMORY | Rec / Memory | REC MODE | Rec |
| VOL + | Audio Vol + | + VOL | Vol + |
| AUDIO − | Audio Vol - | VOL − | Vol - |
| TOP MENU | Top Menu | E-MANUAL D.MENU | D. Menu |
| MENU | Menu | TOP MENU MENU | Menu |
| NEWS/INFO | Up / News/Info | | Up |
| PTY− | Left / PTY- | | Left |
| ENTER | Enter | OK | Ok |
| PTY+ | Right / PTY+ | | Right |
| PTY SEARCH | Down / PTY | | Down |
| RETURN | Return | RETURN BACK | Back |
| ON SCREEN | On Screen | DISPLAY INFO | Info |
| | Stop | | Stop |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Play | PLAY MODE | Play | | |
| | Pause | | Pause | | |
| DOWN - TUNI | I<< / Tuning | | I<< | | |
| UNING - UP | >>I / Tuning Up | | >>I | | |
| - SLOW | << / Slow- | | << | | |
| LOW + | >> / Slow+ | | >> | | |
| AUDIO | Audio | SHIFT + SOUND DUAL | Shift + Dual | | |
| ANGLE | Angle | PICTURE FORMAT | Format | | |
| SUB TITLE | Sub Title | AD SUBT | Subt | | |
| ZOOM | Zoom | ZOOM | Eject | | |
| CHOICE | Choice | CH – | Ch - | | |
| DIMMER SLEE | Dimmer / Sleep | PROG SLEEP | Sleep | | |
| DSP | DSP | B | Green | | |
| SURROUND | Surround | DISC NAV LIST | List | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| On/Off | Power | OK Enter | Ok |
| Audio Off | Mute | Menu Right | Right |
| Slow Down | Ch - | Return | Exit |
| Slow Up | Ch + | Menu Down | Down |
| Stop | Stop | Progr. | Back |
| Pause | Pause | Volume+ | Vol + |
| Subt. | Subt | Next | >>I |
| Auto/Track | Sleep | Volume- | Vol - |
| Rep/A-B | Shift + Text | Top Menu | D. Menu |
| Title | List | 1 | 1 |
| Repeat/1/All | Text | Prev. | I << |
| Zoom | Shift + Eject | 2 | 2 |
| DVD/TV | AV | 3 | 3 |
| Menu | Menu | 4 | 4 |
| Menu Up | Up | 5 | 5 |
| Display | Info | 6 | 6 |
| Menu Left | Left | 7 | 7 |

| Original | Replacement |
|---|---|
| 8 | 8 |
| 9 | 9 |
| +10 | GUIDE |
| 0 | 0 |
| C/CH | PRE-CH |
| ON/Off | SHIFT + Power |
| Record | REC MODE |
| Open/Close | ZOOM |
| F. Forward | >> |
| Rewind | << |
| Play | PLAY MODE |
| Info | SHIFT + INFO |
| Video | SMART |
| Karaoke/Step | SHIFT + Pause |
| Mode | MEDIA |
| Auto Scan | SHIFT + OK |
| Vocal/Assist | SHIFT + VOL + |

| Original | Replacement |
|---|---|
| Echo+ | SHIFT + CH + |
| Tone | SHIFT + VOL - |
| Audio | DUAL |
| Echo- | SHIFT + CH - |
| Angle | FORMAT |