Mandis shop

RC- 180

Original		Replacement	
POWER	Power		Power
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	I<<Volume-	PRESET-	I<< / Preset-
	>>I / Volume+	PRESET+	>>I / Preset+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	<Disc Skip+	REC MODE	Rec / Rec Mode
SHIFT	Shift	LIST SMART	Smart / List
	Channel -	CH PAGE –	CH- / Page-
	Channel +	+ CH PAGE	CH+ / Page+
VDP/TV 2	VDP	DVD 2	2
PHONO 3	Phono	BLUETOOTH 9	9
TUNER 4	Tuner	TUNER 6	6
1 – VCR 5	VCR-1	VIDEO 4	4
VCR – 2 6	VCR-2	TV 1	1

Original		Replacement	
CD 8	CD	CD - STB 3	3
V.AUX/GAME 10	V. AUX	AUX - HDD 7	7
DAT/TAPE 11 /O	DAT/Tape	TAPE 5	5
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
MODE	Mode	TITLE SOUND	Sound / Title
TONE/DIRECT	Direct	EQ SUBTITLE	Subtitle / EQ
MASTER VOL	Master Vol +	+ VOL	Vol +
VIDEO SELECT	Video Select	FORMAT PICTURE	Picture / Format
RDS	RDS	RDS AV INPUT	AV / Input / RDS
PTY	PTY	PROGRAM TV/RADIO	TV/Radio /
MASTER VOL	Master Vol -	VOL –	Vol -
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
T.TONE	T. Tone	Prime Video RANDOM	Blue / Prime Video / Random
CINEMA	Cinema	SURROUND	Eject / Surround
PANEL	Panel	TOP MENU D.MENU	D. Menu / Top
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media

https://remotes.com/Denon/1646939-replacement-remote-for-Denon-RC-180.htm