Mandis shop

RC- 226

Original		Replacement	
RANDOM	Random	Prime Video / RANDOM	Blue / Prime Video / Random
FADER	Fader	DIMMER MUTE	Mute / Dimmer
PROG/DIRECT	Prog/Direct	PROGRAM TV/RADIO	TV/Radio /
PROG/DIRECT	Prog/Direct	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
CALL	Call	PC FAV MARKER	Fav / Marker / PC
PLAY	Play	SLOW ▶	Play / Slow

Original		Replacement	
PAUSE	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
STOP	Stop	HOLD ■	Stop / Hold
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
PITCH −	Pitch-	CH PAGE −	CH- / Page-
PITCH +	Pitch+	CH PAGE +	CH+ / Page+
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+

https://remotes.com/Denon/1627-334-replacement-remote-control-for-Denon-RC226.htm