Mandis shop

Samsung DJ 9600114S

Original		Replacement		Original	Replacement
Power	Power		Power		
Auto	Auto	TV	1		
Recharging	Recharging	LIST SMART	Smart / List		
Spot	Spot	DVD	2		
Max	Max	CD - STB	3		
Start/Stop	Start/Stop	OK	OK		
	Up		Up		
	Right		Right		
	Left		Left		
Manual	Manual	VIDEO	4		
Edge	Edge	TUNER	6		
Clock	Clock	HOME MENU	Menu / Home		
Turbo	Turbo	TAPE	5		
Timer/Daily	Timer/Daily	TIMER SLEEP	Sleep / Timer		
	Nothing	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

https://remotes.at/en/Samsung/1668349-replacement-remote-control-for-Samsung-DJ9600114S.htm