Original	Replacement	Original	Replacement
System Standby	Power	<<	>> / Tune+
Sleep	Sleep / Timer	>>	I<< / Preset-
Master Vol +	Vol +	Play	Play / Slow
Master Vol -	Vol -	Pause	Pause / Step / Freeze
Muting	Mute / Dimmer	Stop	Stop / Hold
Top Menu	Menu / Home	Balance R	Shift + Right
DVD Menu	D. Menu / Top	Balance L	Shift + Left
Up	Up	Bass Boost	Smart / List
Down	Down	Treble-	Yellow / YouTube / Repeat
Right	Right	Treble+	Blue / Prime Video / Random
Left	Left	Bass+	Green / APP / Repeat
Enter	OK	Bass-	Red / Netflix / Search
Recall	Fav / Marker / PC	Tv/Video / ANT	AV / Input / RDS
>>I / CH/ Preset +	>>I / Preset +	Tv CH+	Shift + CH+ /
Preset + Tuner	Shift + >>I / Preset +	Tv CH-	Shift + CH- /
I<</ CH/ Preset -	<< / Tune-	Tv Vol +	Shift + Vol +
Preset - Tuner	Shift + I<< / Preset -	Tv Vol -	Shift + Vol -

Original		Replacement	
TV/VTR D.SKIP	D. Skip / TV/VT	OPT-TOOLS SETUP	Setup / OPT /
VIDEO 1	Video 1	SHIFT + TV 1	Shift + 1
VIDEO 2	Video 2	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD-STB 3	Shift + 3
DVD	DVD	SHIFT + DVD 2	Shift + 2
MD/TAPE	MD/Tape	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
AV	Standby AV	SHIFT + Power	Shift + Power
TOP MENU 1	1 Tuner	TV 1	1
2	2 Tuner	DVD 2	2
DVD MENU 3	3 Tuner	CD-STB 3	3
4	4 Tuner	VIDEO 4	4
5 ENTER	5 Tuner	TAPE 5	5
6	6 Tuner	TUNER 6	6
7	7 Tuner	AUX-HDD 7	7
8	8 Tuner	USB 8	8
9	9 Tuner	BLUETOOTH 9	9

Original		Replacement	
0	0 Tuner	HDMI-SAT 0	0
SHIFT >10 -/--	>10 Tuner/Shift/-/-	-/-- GUIDE EPG	Guide / EPG / -/--
D.TUNING ENTER RETURN	Enter/D. Tuning/Return Tuner	RETURN BACK	Back / Return
CH/PR	Preset- Tuner	CH PAGE −	CH- / Page-
PRESET +	Preset+ Tuner	+ CH PAGE	CH+ / Page+

Original		Replacement	
AV	Standby		Power
VIDEO 1	Video 1	SHIFT + TV 1	Shift + 1
VIDEO 2	Video 2	SHIFT + VIDEO 4	Shift + 4
DVD	DVD	SHIFT + DVD 2	Shift + 2
MD/TAPE	MD/Tape	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD-STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
TOP MENU 1	1	TV 1	1
2	2	DVD 2	2
DVD MENU 3	3	CD-STB 3	3
4	4	VIDEO 4	4
ENTER 5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SHIFT >10 -/--	>10/Shift/-/-	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
0	0	HDMI-SAT 0	0
D.TUNING ENTER RETURN	Enter/D.Tuning/Return	ANGLE INFO	Info / Angle
CH/PR	I<<	TUNE-	<< / Tune-
PRESET +	>>I	PRESET+	>>I / Preset+
	<<	TUNE+	>> / Tune+
	>>	PRESET-	I<< / Preset-
TV/VTR D.SKIP	D.Skip/TV/VTR	OPT-TOOLS SETUP	Setup / OPT /
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
MASTER VOL	Master Vol +	VOL +	Vol +
	Master Vol -	VOL -	Vol -

Original		Replacement	
AV	Standby CD	Power	
VIDEO 1	Video 1	NETFLIX SEARCH	Red / Netflix / Search
VIDEO 2	Video 2	APP REPEAT	Green / APP / Repeat
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DVD	DVD	Prime Video RANDOM	Blue / Prime Video / Random
MD/TAPE	MD/Tape	RDS AV INPUT	AV / Input / RDS
TUNER	Tuner	TIMER SLEEP	Sleep / Timer
TOP MENU 1	1 CD	TV 1	1
2	2 CD	DVD 2	2
DVD MENU 3	3 CD	CD-STB 3	3
4	4 CD	VIDEO 4	4
ENTER 5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX-HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9
0	0 CD	HDMI-SAT 0	0

Original		Replacement	
SHIFT >10 -/--	>10/Shift/-/-- C	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
D.TUNING ENTER RETURN	Enter/D.Tuning/Return CD	ANGLE INFO	Info / Angle
CH/PR	I<< CD	TUNE-	<< / Tune-
PRESET +	>>I CD	PRESET+	>>I / Preset+
<< CD		TUNE+	>> / Tune+
>> CD		PRESET-	I<< / Preset-
Play CD		SLOW	Play / Slow
Pause CD		STEP-FREEZE	Pause / Step / Freeze
Stop CD		HOLD	Stop / Hold
TV/VTR D.SKIP	D.Skip/TV/VTR CD	OPT-TOOLS SETUP	Setup / OPT /
MASTER VOL	Master Vol +	VOL +	Vol +
	Master Vol -	VOL -	Vol -
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
AV	Standby Video	SHIFT +	Shift + Power
TOP MENU 1	1 Video 1	SHIFT + TV 1	Shift + 1
2	2 Video 1	SHIFT + DVD 2	Shift + 2
DVD MENU 3	3 Video 1	SHIFT + CD-STB 3	Shift + 3

Original		Replacement		Original	Replacement
4	4 Video 1	SHIFT + VIDEO 4	Shift + 4		
5 ENTER	5 Video 1	SHIFT + TAPE 5	Shift + 5		
6	6 Video 1	SHIFT + TUNER 6	Shift + 6		
4	7 Video 1	SHIFT + AUX-HDD 7	Shift + 7		
8	8 Video 1	SHIFT + USB 8	Shift + 8		
9	9 Video 1	SHIFT + BLUETOOTH 9	Shift + 9		
0	0 Video 1	SHIFT + HDMI-SAT 0	Shift + 0		
SHIFT >10 -/--	>10/Shift/-/-- Video 1	-/-- GUIDE EPG	Guide / EPG / -/--		
D.TUNING ENTER RETURN	Enter/D.Tuning/Return Video 1	SHIFT + ANGLE INFO	Shift + Info / Angle		
TV/VTR D.SKIP	D.Skip/TV/VTR Video 1	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools		
CH/PR	I<< Video 1		Left		
PRESET +	>>I Video 1		Right		
	<< Video 1		Down		
	>> Video 1		Up		
	Play Video 1	OK	OK		
	Pause Video 1	LIST SMART	Smart / List		
	Stop Video 1	MEDIA DISPLAY	Display / Media		

Original		Replacement	
AV	Standby		Power
VIDEO 1	Video 1	NETFLIX SEARCH	Red / Netflix / Search
VIDEO 2	Video 2	APP REPEAT	Green / APP / Repeat
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DVD	DVD	Prime Video RANDOM	Blue / Prime Video / Random
MD/TAPE	MD/Tape	RDS AV INPUT	AV / Input / RDS
TUNER	Tuner	TIMER SLEEP	Sleep / Timer
TOP MENU 1	1 MD/Tape	TV 1	1
2	2 MD/Tape	DVD 2	2
DVD MENU 3	3 MD/Tape	CD-STB 3	3
4	4 MD/Tape	VIDEO 4	4
ENTER 5	5 MD/Tape	TAPE 5	5
6	6 MD/Tape	TUNER 6	6
7	7 MD/Tape	AUX-HDD 7	7
8	8 MD/Tape	USB 8	8
9	9 MD/Tape	BLUETOOTH 9	9
0	0 MD/Tape	HDMI-SAT 0	0

Original		Replacement	
SHIFT >10 -/--	>10/Shift/-/-- MD/Tape	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
D.TUNING ENTER RETURN	Enter/D.Tuning/Return MD/Tape	ANGLE INFO	Info / Angle
TV/VTR D.SKIP	D.Skip/TV/VTR MD/Tape	OPT-TOOLS SETUP	Setup / OPT /
CH/PR	I<< MD/Tape	TUNE-	<< / Tune-
PRESET +	>>I MD/Tape	PRESET+	>>I / Preset+
	<< MD/Tape	TUNE+	>> / Tune+
	>> MD/Tape	PRESET-	I<< / Preset-
	Play MD/Tape	SLOW	Play / Slow
	Pause MD/Tape	STEP-FREEZE	Pause / Step / Freeze
	Stop MD/Tape	HOLD	Stop / Hold
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
MASTER VOL	Master Vol +	VOL +	Vol +
	Master Vol -	VOL -	Vol -
AV	Standby Video	SHIFT +	Shift + Power
TOP MENU 1	1 Video 2	SHIFT + TV 1	Shift + 1
2	2 Video 2	SHIFT + DVD 2	Shift + 2
DVD MENU 3	3 Video 2	SHIFT + CD-STB 3	Shift + 3

Original		Replacement		Original	Replacement
4	4 Video 2	SHIFT + VIDEO 4	Shift + 4		
5	5 Video 2	SHIFT + TAPE 5	Shift + 5		
6	6 Video 2	SHIFT + TUNER 6	Shift + 6		
7	7 Video 2	SHIFT + AUX-HDD 7	Shift + 7		
8	8 Video 2	SHIFT + USB 8	Shift + 8		
9	9 Video 2	SHIFT + BLUETOOTH 9	Shift + 9		
0	0 Video 2	SHIFT + HDMI-SAT 0	Shift + 0		
SHIFT >10 -/--	>10/Shift/-/-- Video 2	-/-- GUIDE EPG	Guide / EPG / -/--		
D.TUNING ENTER RETURN	Enter/D.Tuning/Return Video 2	SHIFT + ANGLE INFO	Shift + Info / Angle		
TV/VTR D.SKIP	D.Skip/TV/VTR Video 2	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools		
CH/PR	I<< Video 2		Left		
PRESET +	>>I Video 2		Right		
	<< Video 2		Down		
	>> Video 2		Up		
	Play Video 2	OK	OK		
	Pause Video 2	LIST SMART	Smart / List		
	Stop Video 2	MEDIA DISPLAY	Display / Media		