Mandis shop

# Pioneer CU-XC005

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Direct Play (-- | Red / Netflix / Search | Display Up | CH+ / Page+ |
| Direct Play OO | Green / APP / Repeat | Power | Power |
| Direct Play Y | Yellow / YouTube / Repeat | Vol - | Vol - |
| Direct Play [ * | Blue / Prime Video / Random | Vol + | Vol + |
| Menu | Menu / Home | | |
| Sound | Sound / Title | | |
| >> | >> / Tune+ | | |
| Timer | Sleep / Timer | | |
| Cancel | Exit / Cancel / Clear | | |
| I<</- | I<< / Preset- | | |
| Stop | Stop / Hold | | |
| >>I / + | >>I / Preset+ | | |
| Set | Setup / OPT / | | |
| Display/Characte | Info / Angle | | |
| << | << / Tune- | | |
| AUX | 7 | | |
| Display Down | CH- / Page- | | |

https://remotecontrols.at/en/Pioneer/10691-507-replacement-remote-control-for-Pioneer-CU-XC005-AC7.htm