Mandis shop

Original	Replacement	Original	Replacement
Record / OTR	Rec / Rec Mode	P-	CH- / Page-
Standby	Power	P+	CH+ / Page+
Select	Smart / List	Play	Play / Slow
Timer	Sleep / Timer	>>	>> / Tune+
Clear	Exit / Cancel / Clear	<<	<< / Tune-
1	1	Stop	Stop / Hold
2	2	Index	Info / Angle
3	3	SP/LP	D. Menu / Top
4	4	Still	Pause / Step / Freeze
5	5	System	Menu / Home
6	6		
7	7		
8	8		
9	9		
Monitor	Display / Media		
0	0		
OK	OK		

https://remotes.com/Philips/10622-977-replacement-remote-control-for-Philips-PHOTO.htm