Original	Replacement	Original	Replacement
Power	Power	Delete	Exit / Cancel / Clear
Mute	Mute / Dimmer	Vol +	Vol +
Play	Play / Slow	F	Smart / List
Pause	Pause / Step / Freeze	Preset/Folder Up	CH+ / Page+
Stop	Stop / Hold	Vol -	Vol -
USB Rec	Rec / Rec Mode	Preset/Folder	CH- / Page-
I<</Tuning-	I<< / Preset-	1	1
>>I/Tuning+	>>I / Preset+	2	2
Special EQ	Audio / Lang I/II	3	3
Auto DJ	Subtitle / EQ	4	4
Open/Close	Eject / Surround	5	5
Alarm	Zoom / Size	6	6
Sleep	Sleep / Timer	7	7
PTY	TV/Radio /	8	8
Jukebox/Memor	Setup / OPT /	9	9
RDS/Set	Menu / Home	Equalizer	Guide / EPG / -/--
(i)	Info / Angle	0	0

Original	Replacement	Original	Replacement
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
CLOCK Clock	SHIFT + TIMER SLEEP Shift + Sleep / Timer		