Mandis shop

WOX001

| Original | | Replacement | |
|---|---|---|---|
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| | Home | HOME MENU | Menu / Home |
| | Back | RETURN BACK | Back / Return |
| VOL | Vol+ | VOL | Vol+ |
| | [■ ] | OPT-TOOLS SETUP | Setup / OPT / |
| VOL | Vol- | VOL | Vol- |
| | Power | | Power |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://remotecontrols.at/en/Woxter/1067303-79404-replacement-remote-control-for-Woxter-WOX001.html